



Technical Data Sheet

Installation of the DVI-32 8870 / DVI-Ht 8890 Accessory Screen *Kit Number 98-69700*

Publish Date: 6/7/2002

KIT CONTENTS:

Screen

TOOLS REQUIRED:

None

BEFORE YOU BEGIN: Work on a cool stove.

PROCEDURE:

1. Remove the façade by pulling it out at the top and then up and off the DVI-32 or DVI-Ht Firebox.
2. Place the screen onto the DVI Firebox, just in front of the glass panel. Push it fully to the left or right so that the prongs on that side of the screen insert fully into the holes on side of the firebox. Center the screen so that the prongs on both sides of the screen are inserted into the corresponding holes in the DVI Firebox. The screen is now in its proper position and will remain in place.
3. Replace the façade by lining up the 2 receiving knobs located on the bottom of the insert with the 2 hook shaped clamps on the bottom of the façade. Drop the clamps onto the knobs and push the façade assembly onto the firebox until it clicks and locks into place.