

## **Technical Data Sheet**

## Equinox 8000 Replacement Glass Kit Installation Assembly 90-58205

Publish Date: 2/21/2009

Glass Kit #90-58205:

#3110-056: 5 Feet 1/4" Gasket

#3030-048: (1) Glass #5021-060: (8) Glass Clips

#3120-021 (8) Gasket Sections for Glass Clips

#4500-2105 (8) 10-24x3/8" Pan Head Screws

**Tools Required:** 

Scissors
Wire Brush or Steel Wool
Cross-tip Screwdriver

Penetrating Oil

**Before You Begin**: Work on a cool stove. Refer to the diagram on the next page.

## Procedure:

- 1. Remove the front door by lifting it straight up off the hinges with the hinge pins remaining in the door. Take care not to lose any washers placed between the hinge tabs you will need them when the door is returned to the stove. Place the door face down (Use a soft surface for enameled doors).
- 2. To replace the glass gasket in the front door, first apply penetrating oil to each of the eight screws holding the glass clips to the front door. Use the cross-tip screwdriver, to remove these eight screws. Wear work gloves, then carefully lift off the damaged glass and discard it. Pull out the used gasket left in the door and discard it. Clean the gasket channel using steel wool or a wire brush. Wipe the channel clean with a damp cloth to remove any loose residue.
- 3. Peel the paper backing off the gasket and pack it into the prepared gasket channel. Do not stretch or bunch the gasket as it is placed into the channel.
- 4. Carefully place the new glass back onto the door. Secure it by replacing the clips and screws, remembering to place a new flat gasket piece between each retention clip and the glass.
- 5. Return the door to the stove. Ensure any spacer washers are repositioned between the hinge tabs.

