

Harvest Gasket Replacement

Kit # 94-58401

Date: 10/29/2012 Page: 1 of 1

GASKET KIT CONTENTS:

5 Feet – ¼" Rope Gasket (Front Door – Small Dia. Rope) 3 1/2 Feet – ½" Rope Gasket (Side Door – Large Dia. Rope) 2 Feet – 3/8" Rope Gasket (Ash Door – Medium Dia. Rope) 4 1/2 Feet – 3/4" Tape Gasket (Glass – Flat Gasket) 2 Oz Gasket Cement

TOOLS REQUIRED:

BEFORE YOU BEGIN:

Work on a cool stove

Scissors Steel Wool or Wire Brush Phillips Screw Driver Cloth Rag Penetrating Oil

PROCEDURE FOR DOOR GASKET REPLACEMENT

- 1. Remove the side door by lifting it straight up off the hinges with the hinge pins remaining in the door. Place it face down (Use soft surface for enameled doors).
- 2. Pull out used gasket from channel and discard. Clean gasket channel using steel wool or wire brush; remove any residue. Wipe clean with damp rag or cloth.
- 3. Cut the tip off the gasket glue bottle and apply a small bead of the adhesive to the gasket channel. Do not saturate the gasket, as this will cause the gasket to dry and harden.
- 4. When the adhesive becomes "tacky", apply fresh gasket by pushing it into the channel.
- Take care not to stretch or bunch the gasket.
- Do not start in a corner; it will be more easily pulled out.
- Trim any excess with the scissors
- 5. The door should be returned to the stove A.S.A.P. and shut tight to assure a positive seal.
- 6. Repeat this procedure with the front door and the ash pan door.

PROCEDURE FOR WINDOW GASKET REPLACEMENT

HINT: It may be helpful to apply penetrating oil to the heads of the screws that hold the glass retention frame to the front door before attempting to remove them.

- 1. Remove the front door by lifting it straight up off the hinges with the hinge pins remaining in the door. Place it face down (Use soft surface for enameled doors).
- 2. With the phillips screw driver, remove the window frame screws to separate the window frame from the door.
- 3. Carefully lift the glass from the door. Pull off the worn gasket tape.
- 4. Peel the paper backing off the new gasket tape a small section at a time. Wrap the tape gasket around the perimeter of the glass overlapping the front and back of the glass edges.
- 5. Place the gasketed glass onto the door. .
- 6. Screw the window frame back on the door.
- 7. Install the door onto the stove.