



Technical Data Sheet

Tribute DV 8050 Rear Stone Installation Instructions

*Kit #9055-41 (Polished Soapstone)**

Publish Date: 02/17/2006

KIT COMPONENTS:

- 1- Left Rear Stone: 8-5/16" x 14-7/8"
- 1- Right rear Stone: 8-5/16" x 14-7/8"


TOOLS REQUIRED:

Phillips Screwdriver

STEEL (shipped on stove)

2-Side stone clips/heat shields – used to retain the side stones.

Procedure

 **Note:** Always work on a cold stove. Use care in handling stones and enamel front to avoid chipping and scratching of parts.

1. Remove the existing rear panels from the stove by removing the four Phillips head screws holding them in place. Reinsert the screws to plug the existing holes.
2. Install the rear stones by inserting the outside edge first and then rotating the stone in. The stone will drop down into a channel once parallel to the back of the stove.
3. Repeat with second stone.

* Follow these instructions for all Stone Kits:

- 9055-63 Aztec Green Marble
- 9055-53 Autumn Brown Granite
- 9055-41 Polished Soapstone
- 9055-43 Platinum Pearl