

# FMI Colonial 36" Vent Free Firebox

MODELS: V36S, V36, V36SH, V36H, V36AS, V36A, V36ASH, V36AH

	Part Number	Description
1	12116	Screen (2 Required)
2	106691-01	Screen Rod (2 Required)
3	11418	Push-On Nut
4	107944-01	Deflector Hood
5	106651-01	Closure Top Panel
	106684-01	Extruded Louver
6	106651-01	Closure Bottom Panel
	106650-01	Extruded Louver
7	**	Face Weldment
8	106683-01	Firebox Support Leg
9	**	Firebox Bottom
10	107775-01	Access Panel
11	20027	Refractory Retainer
12	**	Firebox Surround
13	**	Firebox Top Shield
14	**	Firebox Top
15	**	Damper Can Collar
16	**	Insulation Pan
17	**	Fireplace Top Insulation
18	**	Fireplace Top
19	20280	Top Spacer
20	**	Fireplace Surround
21	110037-01	Handy Box Assembly
22	106642-01*	Air Rod Retainer
23	21171	Gas Knock-Out Cover
24	21379	Gas Conduit
25	21380	Gas Conduit
26	106703-01*	Air Kit Door Assembly
28	106658-02	Left Refractory Stacked
	108164-02	Left Refractory Herringbone
29	106660-02	Rear Refractory Stacked
	108166-02	Rear Refractory Herringbone
30	106659-02	Right Refractory Stacked
	108165-02	Right Refractory Herringbone
31	106661-02	Bottom Rear Refractory Stacked
	108167-02	Bottom Rear Refractory H'bone
32	106662-02	Bottom Front Refractory Stacked
	108168-02	Bottom Front Refractory H'bone

\* A Models Only

S.M.P. Plus.com