

## FIRE BRICK INSTALLATION

### Mealmaster Cook Stove

1. Remove all old brick and brick clamps.
2. Install new front and rear fire brick. Install them so they are placed with the nine inch (9") side up and the nine and one half inch (9-1/2") side placed side to side.
3. Install the left side fire brick. Install them so they are placed with the eight and one half inch (8-1/2") side up and the eight inch (8") side placed side to side.
4. Install the right side fire brick. Install them so the top with the notch out is facing the fire box.
5. Install the J-21 Right Brick Clamp over the right side brick and the J-22 Left Brick Clamp over the left side brick.

Note - The J-22 Left Brick Clamp is the small "L" shaped piece. To install it, remove the center flat head bolt in the J-12 Left End Top. Rebolt through the J-12 using the longer flat head bolt provided with the J-22.

