

Parts list for Morsø 5660 Standard

Pos. No.	Parts	
1	Bottom plate 5600	44565021
2	Front frame 5600	44560221
3	Door 5600	44560321
4	Rear plate 5600	44560400
5	Top plate 5600	44560521
6	Top plate Inclined 5600	44560800
7	Side plate right 5600 EN	34560600
8	Side plate left 5600 EN	34560700
9	Air Canal Top inside 5600	34560900
10	Air Canal Rear 5600	44561000
11	Air Canal Inclined 5600	34561100
12	Stop bar 5600	71561100
13	Screw	73863100
14	Flue collar	44344721
15	Stone Bottom, right 5600 NA	79562000
16	Glass 5600	79560100
17	Stone back 5600 NA	79561800
18	Stone side NA	79561900
20	Vertical baffle plate	79560700
21	Insert box 5600 NA	71560121
22	Insert Frame 5600 NA	54561721
23	Secondary draft control	71560500
24	Handle sek. draught control	71560600
25	Door fitting	71810100
26	Hinge pin	74701000
27	Screw	738615
28	Washer	791891
29	Screw	731630
30	Screw	731625
31	Screw	73861100
32	Screw	731640
33	Glass fitting	54146361
34	Screw	73850800
35	Distance tube	71562600
36	Distance tube	71562700
37	Washer	79189500
38	Distance tube	54202500
39	Screw	73860900
40	Screw	73865500
41	Cover f. Pilot air 5600	71561000
43	Screw	73860900
44	Airtight Canal 5600	34561200
45	Baffle plate 5600	44561400
46	Baffle plate, stainless	71561300
47	Screw	73886000
48	Screw	74160804
49	Adjustment base 5600	71563400
50	Screw	73863500
53	Washer	79189800
54	Screw	73861800

Pos. No.	Parts	
56	Axis for handle	71562061
57	Door handle, stainless steel	75263600
58	Hinge pin	541082
59	Screw	73960700
60	Closing plate	71562100
62	Front Cover Fitting	71562300
64	Washer	746006
68	Stone Bottom, left 5600 NA	79562100
69	Adhesive fibre for door glass	79074500
70	Spring	79049100
71	Screw	731606
72	Insulation	79561300
73	Screw	743625
74	Washer	79190100
75	Screw	791835
91	Spring for Handle	79048800
92	Hinge pin	74201900
93	Washer	79189400
94	Screw	73951600
95	Cover plate for air tight	73563300
96	Split pin	73530700
97	Screw	739630