

**Jotul #20**

<b>Item #</b>	<b>Part #</b>	<b>Description</b>
1	4250901	Left Trim Panel
2	4250902	Right Trim Panel
4	4250906	Front Plate
5	4225874	Baffle
8	4225872	Damper
11	4079280	Outlet
12	4705966	Speed Nut
15	4504003	Slider of Central Grate
16	4079304	Protecting Plate for Fan
17	4705963	Hexagon socket Set Screws M6x40mm
18	4079279	Ashpan
19	4766129	Adjustable secondary air spoiler
20	4504005	Support of magnetic lock
21	4077688	Magnetic Lock
22	4250898	Ashpan door Frame
23	4504050	Slider of primary air
24	4504049	Flap of Primary Air
26	4225873	Side Burn Plate
27	4766138	Stop for Side Burn Plate
28	4225870	Rear Firebox Burn Plate
29	4225871	Bottom Grate
30	4225878	Cleaning Grate
31	4225875	Central Bottom Grate
38	4703936	Axis for Lower Panel
39	4250899	Ashpan Door
41	4504055	Lower Front Panel
42	4504051	Snap lock for ashpan door
43	4705962	Axis for snap lock
45	0231700	Splined pin
46	4774798	Ceramic Glass
47	4250905	Glass Door
48	0294045	Screw HB M8 x 20 without head
54	4705967	Axis for Handle
55	4705947	Hexagon socket set screws M4 x 10
57	4766153	Glass tightener
58	4766152	Footstep Liner
60	4225331	Stove Operating Tool
61	4705951	Hexagon key ref. 6784

Not all parts are available on older units. If you do not see the part you need listed on the stove page, please contact us at 603-522-8216 for more information.

\*Unauthorized taking of this document is forbidden.