

Vogelzang TR008 Parts List

Part No.	Description	Qty.
08-1	Main Fire Box Assembly	1
08-2	Back Heat Shield Assembly.....	1
08-3	Door Assembly (see pg 20 for parts).....	1
08-4	Front Heat Shield Curtain	1
08-5	Leg.....	4
08-6	Secondary Air Duct Frame	1
08-7	Air Pipe "A"	1
08-8	Air Pipe "B"	2
08-9	Air Pipe "C"	1
08-10	Air Pipe "D"	1
08-11	Air Pipe Retainer	5
08-12	SS Air Pipe Retainer Screw.....	5
08-13	Fire Bricks	
08-13A	Fire Brick "A" (9"x4.5"x1.25").....	16
08-13D	Fire Brick "D"	5
08-13E	Fire Brick "E"	1
08-13F	Fire Brick "F"	2
08-13G	Fire Brick "G"	1
08-13H	Fire Brick "H"	1
08-13K	Fire Brick "K"	1
08-14	Hearth Trim	1
08-15	Top Trim.....	1
08-16	Bottom Heat Shield.....	1
08-17	Back Heat Shield Deflector	1
08-18	Ceramic Fiberboard, Rear - 14"x 14"	1
08-19	Ceramic Fiberboard, Front - 14"x 9-5/8".....	1
08-20	KAO Wool Insulating Pad	2
08-21	Door Pin	2
08-HP	Hardware Pack	1
08-26	Phillips Head Machine Screw (lg)	4
08-27	Phillips Head Machine Screw (sm)	3
08-28	Hex Nut	4
F-6	Blower Assembly	1
F-6G	Ceramic Gasket	1
F-6S	Phillips Head Machine Screw (sm)	4
08-03	Door Assembly (complete)	1
08-41	Door Casting 1	1
08-42	Air Wash Casting	1
08-43	Door Vent Slider	1
08-44	Slide Retainer	2
08-45	Slide Handle.....	1
08-46	Door Glass	1
08-47		
08-48	Glass Retainer	2
08-49	Flat Head Phillips Screw	6
08-50	SS Hex Screw	12
08-51	SS Washer	12
08-52	Window Gasket	1
08-53	Door Gasket.....	1
08-54	Door Handle Assembly	1
08-55	Door Latch	1