

Part Number	Description
Burner Assemblies	
AA-11-00076	Single Burner Assembly NG MIG-30 (1990 - 1991)
AA-11-00077	Single Burner Assembly LP MIG-30 (1990 - 1991)
AA-11-00078	Single Burner Assembly NG MIG-36 (1990 - 1991)
AA-11-00079	Single Burner Assembly LP MIG-36 (1990 - 1991)
AA-11-00121	Dual Burner Assembly NG MIG-30 (1992)
AA-11-00122	Dual Burner Assembly LP MIG-30 (1992)
AA-11-00123	Dual Pan Burner Assembly NG MIG-36 (1992)
AA-11-00124	Dual Pan Burner Assembly LP MIG-36 (1992)
AA-11-00171	Dual Pan Burner Assembly NG MIG-30 (1993 - 1995)
AA-11-00172	Dual Pan Burner Assembly LP MIG-30 (1993 - 1995)
AA-11-00174	Dual Burner Assembly NG MIG-36 (1993 - 1995)
AA-11-00175	Dual Burner Assembly LP MIG-36 (1993 - 1995)
HA-12-00256	Valve Assembly NG MIG-32 (1996 - 1998)
HA-12-00257	Valve Assembly LP MIG-32 (1996 - 1998)
HA-12-00258	Valve Assembly NG MIG-40 (1996 - 1998)
HA-12-00259	Valve Assembly LP MIG-40 (1996 - 1998)
AA-11-00280	Valve & Burner Tube Ass'y NG MIG-32 (1998)
AA-11-00281	Valve & Burner Tube Ass'y LP MIG-32 (1998)
AA-11-00282	Valve & Burner Tube Ass'y NG MIG-40 (1998)
AA-11-00283	Valve & Burner Tube Ass'y LP MIG-40 (1998)
HA-12-00260	Burner tube Weldment NG MIG-32 (1996 - 1998)
HA-12-00268	Burner tube Weldment NG MIG-40 (1996 - 1998)
HA-12-00272	Burner tube Weldment LP MIG-32 (1996 - 1998)
HA-12-00273	Burner tube Weldment LP MIG-40 (1996 - 1998)
05-04-00012	Pilot assembly MIG-30/36 (1990 - 1991)
05-04-00016	Pilot Hood & Ignitor dual burner MIG-30/36 (1992-1995) SEE REMARKS
05-04-00024	Pilot assembly with T-pile and Ignitor - NG & LP MIG-32/40 (1996)
05-04-00025	Pilot assembly with T-pile and Ignitor - LP MIG-32/40 (1996)
05-04-00026	Pilot assembly with T-pile and Ignitor - NG MIG-32/40 (1997-1998)
05-04-00027	Pilot assembly with T-pile and Ignitor - LP MIG-32/40 (1997-1998)
55-02-00072	Pilot Gas Tube (1991 - 1995) (MIG-30 & MIG-36)
HA-11-00377	Pilot Gas Line MIG-32 (1996 - 1998)
HA-11-00378	Pilot Gas Line MIG-40 (1996)
HA-11-00414	Pilot Gas Line MIG-40 (1997 - 1998)
HA-11-00379	Main Gas Line MIG-32 (1996 - 1998)
HA-11-00380	Main Gas Line MIG-40 (1996)
HA-11-00413	Main Gas Line MIG-40 (1997 - 1998)
05-02-00237	Hi/Lo Regulator Knob NG (1990 - 1998)
05-02-00236	Hi/Lo Regulator Knob LP (1990 - 1998)
65-03-00018	Pilot orifice LP MIG-30/36 (1990 - 1995)
65-03-00021	Pilot orifice NG MIG-30/36 (1990 - 1995)
65-06-00949	Pilot orifice NG (ITT .024) MIG32 & MIG40 (1996 - 1998)
65-06-00950	Pilot orifice LP (ITT .013) MIG 32 & MIG-40 (1996 - 1998)
HA-09-00191	Main orifice - NG - (1991) # 33 - includes both male and female orifices
HA-11-00075	Main Orifice MIG-36 NG (1991)
HA-11-00042	Main orifice - LP - (1991) # 51 - includes both male and female orifices
HA-11-00076	Main Orifice MIG-36 LP (1991)
HA-12-00139	Main Orifice MIG-30 Dual NG (1992)
HA-12-00140	Main Orifice MIG-36 Dual NG (1992)
HA-12-00141	Main Orifice MIG-30 Dual LP (1992)
HA-12-00142	Main Orifice MIG-36 Dual LP (1992)
HA-12-00215	Main Orifice MIG-30 Dual NG (1993 - 1995)
HA-12-00216	Main Orifice MIG-36 Dual NG (1993 - 1995)
HA-12-00217	Main Orifice MIG-30 Dual LP (1993 - 1995)
HA-12-00218	Main Orifice MIG-36 Dual LP (1993 - 1995)
HA-19-00141	Main Orifice MIG-40 NG #30 (1996-1998)
HA-11-00416	Main Orifice MIG-40 LP #49 (1996-1998)
HA-11-00399	Main Orifice MIG-32 NG #40 (1996-1998)

Part Number	Description
Burner Assemblies - Continued from Previous Page	
HA-27-00016	Main Orifice MIG-32 LP #52 (1996-1998)
05-07-00061	Thermopile MIG-30/36 (1990 - 1995)
05-07-00065	Thermopile (ITT) MIG-32/40 (1996 - 1998) Fat Style T-Pile
05-02-00181	Main gas valve (1990 - 1992)
05-02-00215	Electronic Ignition Valve - NG
05-02-00227	Electronic Ignition Lock Out Box - NG
05-02-00238	Main gas valve NG MIG-30/36, MIG-32/40 (1990 - 1998)
05-02-00239	Main gas valve LP MIG-30/36, MIG-32/40 (1990 - 1998)
Blowers	
First 100 units utilized a blower system mounted outside of the unit. So both of these configurations will need a blower	
AA-11-00091	Blower kit with rheostat MIG-30 (1991, 1992)
AA-11-00092	Blower kit with rheostat MIG-36 (1991, 1992)
AA-11-00120	Blower kit with rheostat MIG-30 (1993 - 1995)
AA-11-00127	Blower kit with rheostat MIG-36 (1993 - 1995)
15-02-00042	Blower w/motor (MIG30/36 1991-1995 MIG32/40 1996-1998) (Squirrel cage 7" long x 1 3/4" dia
10-01-00046	Rheostat (MIG30/36 1991-1995 MIG32/40 1996-1998)
05-01-00157	Thermodisc (MIG30/36 1991-1995 MIG32/40 1996-1998)
05-01-00191	Magnetic Thermo-disc bracket assembly
15-02-00033	Blower w/motor 4 1/2" Dayton transflow
Logs	
HA-12-00077	Cement Log Set & Rack MIG-30 (1990)
HA-12-00078	Cement Log Set & Rack MIG-36 (1990)
HA-12-00014	Log Rack MIG-30 (1990)
HA-12-00088	LogRack MIG-36 (1990)
HA-10-00140	Cement Bottom Log Front (1990)
HA-10-00141	Cement Bottom Log Back (1990)
HA-10-00142	Cement Top Logs (2) (1990)
35-01-00136	Dual bottom log - front MIG-30/36 (1991)
35-01-00165	Dual bottomfront log with coal bed MIG-30/36 (1992)
HA-11-00309	Log Clip MIG-30/36
35-01-00135	MIG30/36 Dual Bottom Coal Bed (1991 model only)
35-01-00254	MIG30/36 Coal Bed for use with 35-01-00181 (1992 model only)
35-01-00181	MIG30/36 Dual front log (1991 - 1995)
35-01-00137	MIG30/36 Dual bottom log rear (1991 - 1995)
35-01-00138	MIG30/36 Dual top logs (each) (1991 - 1995)
35-01-00239	Glowing Inswool
35-01-00213	Log set with coals MIG-32 (1996 - 1998)
35-01-00212	Firebrick kit MIG-30 & MIG-32 (1996 - 1998)
HA-11-00376	Bracket - firebrick kit (2 needed) MIG30 & MIG-32 (1996 - 1998)
35-01-00214	Log set with coals MIG-40 (1996 - 1998)
35-01-00215	Firebrick kit MIG-36 & MIG-40 (1996 - 1998)
HA-11-00370	Side brick clip for MIG36 & MIG40 - RH (1996 - 1998)
HA-11-00371	Side brick clip for MIG36 & MIG40 - LH (1996 - 1998)
35-01-00187	Baq of coals (1993 - 1998)
Miscellaneous	
65-06-00367	Magnet (1)
AA-11-00226	MIG36 Baffle Replacement
AA-11-00351	Glass Gasket replacement kit MIG-30/32 (1990 - 1998)
AA-11-00352	Glass Gasket replacement kit MIG-36/40 (1990 - 1998)
65-06-00166	Glass - MIG-30/32 (1990 - 1998) Order AA-11-00351 Glass Gasket
65-06-00167	Glass - MIG-36/40 (1990 - 1998) Order AA-11-00352 Glass Gasket
HA-11-00263	MIG30 Top Glass Bracket -Outside Piece
HA-12-00180	MIG30 Top Glass Bracket - Inside Piece
HA-11-00265	MIG36 Top Glass Bracket -Outside Piece
HA-12-00181	MIG36 Top Glass Bracket - Inside Piece
45-01-00063	Draft diverter MIG-30/32
45-01-00064	Draft diverter MIG-36/40
65-06-00149	Piezo igniter
05-01-00154	Flue switch (MIG30/MIG36 1991-95 MIG32/MIG40 1996-98)
10-10-00104	On/off switch
65-06-01049	Black Touch up paint
65-06-00474	Magnetic Tape