

Vermont Castings Stardance UVS27R Part List

## UVS27R, UVS27M Vent Free Gas Heaters

Models 4030, 4040, 4085, 4090(continued)

Ref.	Description	UVS27
1.	Gas Log Assembly - UVS27	20005005
1a.	Log #V40 Rear UVS27	20005006
1b.	Log #V42 Left UVS27	20005008
1c.	Log #V41 Right UVS27	20005007
1d.	Lava Rocks Burner	57897
2a.	Manifold Assy. - UVS27R	20003739
2b.	Manifold Assy. - UVS27M	20004935
3.	Damper Steel Handle/Screw (Stardance Operable Door Only)	5004265
4.	Handle Package, Ceramic w/Screw (Stardance Operable Door Only)	0004342
5.	Trim ON/OFF Switch	53606
6.	Screen UVS27	20005009
7.	Glass Frame Assembly - SDV30	30000127
8.	Glass w/Gasket (Comes with UVGDCFK)	20005018
9a.	Valve NG Honeywell - VS84212003	10000235
9b.	Valve LP Honeywell - VS84212011	10000242
9c.	Valve MN Eurosit 0.630.564	20001354
9d.	Valve MP Eurosit 0.630.563	20001355
10a.	Oxygenerator, NG OP #8204	55464
10b.	Oxygenerator, LP OP #8404	55465
10c.	Oxygenerator, NG OP #8202	20004435
10d.	Pilot ODS TP OP #8402	20001357
11.	Front, Stardance OP DR (Stardance Only)	Refer to Enamel Parts Chart Page 36
12.	Door, Left - Stardance	Refer to Enamel Parts Chart Page 36
13.	Door, Right - Stardance	Refer to Enamel Parts Chart Page 36
14a.	Burner Housing Assy. - JUV NG	20003130
14b.	Burner Housing Assy. - LP	20004995
15.	Bracket, Rear Log - JUV	20003274
16a.	Orifice Hood #69 (.0292") - Front - LP	30000513
16b.	Orifice Hood #54 (.055") - Front - NG	20000130
16c.	Orifice Hood #54 (.055") - Rear - LP	20000130
16d.	Orifice Hood #44 (.086") - Rear - NG	30000334
17.	Ignitor Piezo - Honeywell #396079	20000062
18.	Gasket, Base Pan Inner	20002566
19.	Bracket Support Right Log	20004920
20.	Bracket Support Left Log	20005022
21.	Grate Decorative Burner	20003022
22.	Grille, UV30	30000393
23.	Mesh, Grille - UV30	30000508
24.	Top, Stardance UV/PDV	Refer to Enamel Parts Chart Page 36
25.	Front, HM-VC	Refer to Enamel Parts Chart Page 36
26.	Door, Control - FS/HM	Refer to Enamel Parts Chart Page 36
27.	Cover, Valve w/Piezo	51851
28.	Catalyst, RUV (not shown) (Comes with UVGDCFK)	30000506

Ref.	Description	UVS27
29.	Left End - Hearthmount	Refer to Enamel Parts Chart Page 36
30.	Right End - Hearthmount	Refer to Enamel Parts Chart Page 36
31.	Left End - Freestanding	Refer to Enamel Parts Chart Page 36
32.	Right End - Freestanding	Refer to Enamel Parts Chart Page 36

Shell Enamel Part Numbers - Hearthmount					
Color	Top	Left End	Right End	Front	Control Door
Classic	1301083	30001282	30001281	1301129	1301087
Sand	1321083	30001303	30001302 $\times$	1321129	1321087
Midnight	1341083	30001310	30001309	1341129	1341087

Shell Enamel Part Numbers - Freestanding						
Color	Top	Left End	Right End	Front (OP)	Left Door	Right Door
Classic	30001278	30001280	30001287	30001496	30001139	30001138
Red	30001285	30001287	30001286	30001261	30001263	30001262
Sand	30001299	30001301	30001300	30001267	30001269	30001268
Midnight	30001306	30001308	30001307	30001270	30001272	30001271
Green	30001292	30001294	30001293	30001264	30001266	30001265
Moonlight	30001319	30001321	30001320	30001314	30001316	30001315
Suede Brown	30002554	30002547	30002548	30002550	30002552	30002551