

Town and Country WS38 Parts List

1.

TCWS.38CE2 Replacement Parts

(WHEN ORDERING, INCLUDE PART NUMBER WITH DESCRIPTION)

ITEM	DESCRIPTION	PART NO.	ITEM	DESCRIPTION	PART NO.
#1	TCWS BODY ASSEMBLY	TCWS.38CE	*#5	FINISHING TOUCH TRIM KIT	TCWS.8330
#2	GLASS ASSEMBLY	GLAS.8328	#6	ORIFICE (2pcs)	5022.3
#3	FRAMING KIT	TCWS.38FRKIT	#7	MAIN GAS SUPPLY TUBES (3pcs)	5019.223
#4	PANEL SETS		#8	BURNER SUPPORT	9498
	BLACK PORCELAIN	TCPN.WS38BK.C	#9	PILOT ASSEMBLY	TCRP.5005025F
	BROWN PORCELAIN	TCPN.WS38CB.C	#10	1/2" TEE	5019.013
	COPPER PORCELAIN	TCPN.WS38CU.C			
	TITANIUM PORCELAIN	TCPN.WS38TI.C		*NOT SHOWN	

2.

Replacement Parts – Maestro Control System

(WHEN ORDERING, INCLUDE PART NUMBER WITH DESCRIPTION)

ITEM	DESCRIPTION	PART NO.	ITEM	DESCRIPTION	PART NO.
#1	CONTROL ASSEMBLY KIT	TCRP.9271A	#5	COMMUNICATION CABLE KIT	5005.06
#2	BULKHEAD ASSEMBLY KIT	TCRP.9285	#6	CONTROL BOX KIT	TCRP.8270
#3	UTILITY BOX ASSEMBLY KIT	TCRP.5024405	#7	REMOTE HAND SET	5005.05
#4	WALL CONTROL ASSEMBLY KIT	TCRP.5005043	#8	TEST FITTING	5019.104