

Nestor Martin A80 Oil

1.

1	21675	Loading Lid A80 MF
2	21674	Top Plate A80 MF
3	RO1141	Rope 9mm dia *Hard Glass Fibre
4	22163	Halfmoon Blank Plate A80 MF
8	FF5006	M5 x 20 Pozi Pan BZP
9	MS9071	Coal Kit 8 H1 H2
10	CE102	Ceramic Coal Base Oil
11	CE101	Coal Set Loose for Oil
12	FF5013	M5 x 20 Pozi CSK BZP
13	26231	Washer Concave for Enamel Flue
14	38483	Flue Spigot 4in H1 S80 Gas C/F
15	FF5006	M5 x 20 Pozi Pan BZP
16	30813	Top Flue Adaptor Outer Section
17	30803	Gasket Ceramic Between Inner
18	30812	Top Flue Adapter Internal Part
19	30804	Gasket Ceramic between Inner
20	FF5000	M5 Nut Full BZP
21	FF5001	M5 Washers Plain BZP
22	FF5006	M5 x 20 Pozi Pan BZP
23	FF5000	M5 Nut Full BZP
24	FF5013	M5 x 20 Pozi CSK BZP
25	21673	Heat Exchanger Cast Gas
26	40785	Paint Spray Cast Black Stove
27	MS38548	Glove Red Leather Pair
28	29757	Tool Ash Pan - Cat. Remover
29	FF0602	Screw 6mm x 25mm BZP Pan Head
31	MS999	No Part Number Listed
32	22148	Rear Cast body B80 A80 MF
33	FF5028	M5 Stud 50mm
34	FF5001	M5 Washers Plain BZP
35	FF5000	M5 Nut Full BZP
36	MS999	No Part Number Listed
37	FF5006	M5 x 20 Pozi Pan BZP
38	FF5010	M5 x 10 Pozi CSK BZP
39	FF5030	M5 Washer Tooth Lock Ext
40	MS999	No Part Number Listed
41	32535	Hinge Top Pin FB50 FB80
42	34699	Spacer handle Hearth & Insert

Woodman's Parts Plus  
[www.woodmanspartsplus.com](http://www.woodmanspartsplus.com)

43	FF8000	M8 Nut Full BZP
44	FF8000	M8 Nut Full BZP
45	MS999	No Part Number Listed
46	MS999	No Part Number Listed
47	FF5005	M5 x 16 Pozi Pan BZP
48	30271	Glass A80 Oil (Aarhus) Middle
49	RO1121	Rope 8mm dia Glass Fibre
50	31297	Rope Oval Hearth stove doors
51	32521	Furnace Door Blue A80 Hearth
51	32522	Furnace Door Green A80 Hearth
51	32519	Furnace Door Slate A80 Hearth
51	32524	Furnace Door Nickel A80 Hearth
52	MS999	No Part Number Listed
53	MS999	No Part Number Listed
54	MS999	No Part Number Listed
55	31856	Glass Clip Support Seal
56	13479	Glass Retaining Clip Harmony
57	FF5042	M5 x 10 Pozi Pan S/Steel
58	MS999	No Part Number Listed
59	FF5006	M5 x 20 Pozi Pan BZP
60	FF5000	M5 Nut Full BZP
61	FF5001	M5 Washers Plain BZP
62	FF5028	M5 Stud 50mm
63	20194	Switch Less Button Ignition
63	20195	Button Cap - Push Ignition
64	28053	Ignition Indicator Light
66	FF5020	M5 x 20 Hex Head Set Screw BZP
67	FF5020	M5 x 20 Hex Head Set Screw BZP
68	MS1121	Transformer Kit all Models
69	MS1121	Transformer Kit all Models
70	MS999	No Part Number Listed
71	MS999	No Part Number Listed
72	MS999	No Part Number Listed
73	MS2110	Split Cotter Pin 1 1/4"x3/32
74	39479	Rod Knob to Oil Valve H8
75	MS999	No Part Number Listed
76	FF0602	Screw 6mm x 25mm BZP Pan Head
77	MS999	No Part Number Listed
78	18365	Grub Screw Ash Pan Door Hinge
79	MS999	No Part Number Listed
80	FF5006	M5 x 20 Pozi Pan BZP

81	MS999	No Part Number Listed
82	31976	Glass Holding Clips A80/100
82	31977	Glass Holding Clips A80/100
83	MS999	No Part Number Listed
84	31976	Glass Holding Clips A80/100
84	31977	Glass Holding Clips A80/100
85	32488	Door Lower A80
86	30033	Badge Nestor Martin with bolt
87	FF8000	M8 Nut Full BZP
88	34699	Spacer handle Hearth & Insert
89	12501	Washer Sprung for Handles
90	34377	Handle Cast All Hearth Stoves
91	FF8001	M8 Washers Plain BZP
92	FF8013	M8 x 30 Hex Head Set Screw BZP
93	FF8000	M8 Nut Full BZP
94	FF3004	M3 x 10 Pozi Pan BZP
95	FF3001	M3 Washer Plain BZP
96	FF3000	M3 Nut Full BZP
98	2805	Draught Stabilizer 5in al Efel
98	DR031	Draught Control Assy H3/C'man
99	DR014	Magnet Anisotropic Large
99	DR015	Magnet Anisotropic Small
100	DR031	Draught Control Assy H3/C'man
100	DR017	Control Cable Long 460mm
105	MS2110	Split Cotter Pin 1 1/4"x3/32
107	FF8000	M8 Nut Full BZP
108	MS999	No Part Number Listed
109	33900	Bolt Eccentric door handle M8
110	FF8013	M8 x 30 Hex Head Set Screw BZP
111	34701	Handle steel B80
112	12501	Washer Sprung for Handles
113	34699	Spacer handle Hearth & Insert
114	MS999	No Part Number Listed

**2.**

9	MS9071	Coal Kit 8 H1 H2
10	CE102	Ceramic Coal Base Oil
11	CE101	Coal Set Loose for Oil
12	FF5013	M5 x 20 Pozi CSK BZP
13	26231	Washer Concave for Enamel Flue
14	38483	Flue Spigot 4in H1 S80 Gas C/F
15	FF5006	M5 x 20 Pozi Pan BZP

Woodman's Parts Plus  
[www.woodmanspartsplus.com](http://www.woodmanspartsplus.com)

16	30813	Top Flue Adaptor Outer Section
17	30803	Gasket Ceramic Between Inner
18	30812	Top Flue Adapter Internal Part
19	30804	Gasket Ceramic between Inner
20	FF5000	M5 Nut Full BZP
21	FF5001	M5 Washers Plain BZP
22	FF5006	M5 x 20 Pozi Pan BZP
23	FF5000	M5 Nut Full BZP
24	FF5013	M5 x 20 Pozi CSK BZP
25	21673	Heat Exchanger Cast Gas
26	40785	Paint Spray Cast Black Stove
27	MS38548	Glove Red Leather Pair
28	29757	Tool Ash Pan - Cat. Remover
29	FF0602	Screw 6mm x 25mm BZP Pan Head
31	MS999	No Part Number Listed
32	22148	Rear Cast body B80 A80 MF
33	FF5028	M5 Stud 50mm
34	FF5001	M5 Washers Plain BZP
35	FF5000	M5 Nut Full BZP
36	MS999	No Part Number Listed
37	FF5006	M5 x 20 Pozi Pan BZP
38	FF5010	M5 x 10 Pozi CSK BZP
39	FF5030	M5 Washer Tooth Lock Ext
40	MS999	No Part Number Listed
41	32535	Hinge Top Pin FB50 FB80
42	34699	Spacer handle Hearth & Insert
43	FF8000	M8 Nut Full BZP
44	FF8000	M8 Nut Full BZP
45	MS999	No Part Number Listed
46	MS999	No Part Number Listed
47	FF5005	M5 x 16 Pozi Pan BZP
48	30271	Glass A80 Oil (Aarhus) Middle
49	RO1121	Rope 8mm dia Glass Fibre
50	31297	Rope Oval Hearth stove doors
51	32521	Furnace Door Blue A80 Hearth
51	32522	Furnace Door Green A80 Hearth
51	32519	Furnace Door Slate A80 Hearth
51	32524	Furnace Door Nickel A80 Hearth
52	MS999	No Part Number Listed
53	MS999	No Part Number Listed
54	MS999	No Part Number Listed
55	31856	Glass Clip Support Seal
56	13479	Glass Retaining Clip Harmony
57	FF5042	M5 x 10 Pozi Pan S/Steel
58	MS999	No Part Number Listed

59	FF5006	M5 x 20 Pozi Pan BZP
60	FF5000	M5 Nut Full BZP
61	FF5001	M5 Washers Plain BZP
62	FF5028	M5 Stud 50mm
<b>3.</b>		
63	20194	Switch Less Button Ignition
63	20195	Button Cap - Push Ignition
64	28053	Ignition Indicator Light
66	FF5020	M5 x 20 Hex Head Set Screw BZP
67	FF5020	M5 x 20 Hex Head Set Screw BZP
68	MS1121	Transformer Kit all Models
69	MS1121	Transformer Kit all Models
70	MS999	No Part Number Listed
71	MS999	No Part Number Listed
72	MS999	No Part Number Listed
73	MS2110	Split Cotter Pin 1 1/4"x3/32
74	39479	Rod Knob to Oil Valve H8
75	MS999	No Part Number Listed
76	FF0602	Screw 6mm x 25mm BZP Pan Head
77	MS999	No Part Number Listed
78	18365	Grub Screw Ash Pan Door Hinge
79	MS999	No Part Number Listed
80	FF5006	M5 x 20 Pozi Pan BZP
81	MS999	No Part Number Listed
82	31976	Glass Holding Clips A80/100
82	31977	Glass Holding Clips A80/100
83	MS999	No Part Number Listed
84	31976	Glass Holding Clips A80/100
84	31977	Glass Holding Clips A80/100
85	32488	Door Lower A80
86	30033	Badge Nestor Martin with bolt
87	FF8000	M8 Nut Full BZP
88	34699	Spacer handle Hearth & Insert
89	12501	Washer Sprung for Handles
90	34377	Handle Cast All Hearth Stoves
91	FF8001	M8 Washers Plain BZP
92	FF8013	M8 x 30 Hex Head Set Screw BZP
93	FF8000	M8 Nut Full BZP
94	FF3004	M3 x 10 Pozi Pan BZP
95	FF3001	M3 Washer Plain BZP
96	FF3000	M3 Nut Full BZP
98	2805	Draught Stabilizer 5in al Efel
98	DR031	Draught Control Assy H3/C'man
99	DR014	Magnet Anisotropic Large

99	DR015	Magnet Anisotropic Small
100	DR031	Draught Control Assy H3/C'man
100	DR017	Control Cable Long 460mm
105	MS2110	Split Cotter Pin 1 1/4"x3/32
107	FF8000	M8 Nut Full BZP
108	MS999	No Part Number Listed
109	33900	Bolt Eccentric door handle M8
110	FF8013	M8 x 30 Hex Head Set Screw BZP
111	34701	Handle steel B80
112	12501	Washer Sprung for Handles
113	34699	Spacer handle Hearth & Insert
114	MS999	No Part Number Listed
116	40307	Pipe to Burner H8 Oil
116	1504	Nut Oil Connection
116	112	Olive
118	26428	Catalyser 8 inch Mk2 Single
119	23908	Catalyser Support 8 inch MK2
126	39674	Oil Burner 8in A80 B80
130	29485	Ignition Port Gasket for Guide
131	29482	Ignition Port Guide(swan neck)
132	FF4000	M4 Nut Full BZP
133	26796C	Igniter Oil Stove inc. Gasket
134	29632	Screw M4 x 10mm
135	16149	Decoking Assembly
137	FF8012	M8 x 25 Hex Head Set Screw BZP
138	31756	Power Cord Oil Stove UK Spec
139	MS999	No Part Number Listed
140	MS999	No Part Number Listed
145	DR031	Draught Control Assy H3/C'man
145	DR010	Sub Frame Draught Stabilizer
146	DR031	Draught Control Assy H3/C'man
146	DR012	Spindle Cable Actuator
147	DR031	Draught Control Assy H3/C'man
147	DR021	Actuator Shaft End Cap
148	DR031	Draught Control Assy H3/C'man
148	DR011	Cam Draught Stabilizer
149	DR031	Draught Control Assy H3/C'man
149	DR014	Magnet Anisotropic Large
150	DR031	Draught Control Assy H3/C'man
150	DR015	Magnet Anisotropic Small
151	DR031	Draught Control Assy H3/C'man
151	DR013	Spring Return Mechanism
152	DR031	Draught Control Assy H3/C'man
152	FF3019	M3 x 8 mm Bolt Hex Head
153	DR031	Draught Control Assy H3/C'man

153	FF3000	M3 Nut Full BZP
154	DR031	Draught Control Assy H3/C'man
154	FF3000	M3 Nut Full BZP
155	DR031	Draught Control Assy H3/C'man
155	FF3001	M3 Washer Plain BZP
156	DR031	Draught Control Assy H3/C'man
156	FF3019	M3 x 8 mm Bolt Hex Head
157	DR031	Draught Control Assy H3/C'man
157	DR017	Control Cable Long 460mm
158	DR031	Draught Control Assy H3/C'man
159	DR031	Draught Control Assy H3/C'man
159	FF3001	M3 Washer Plain BZP
160	DR031	Draught Control Assy H3/C'man
160	DR019	Brass Channel Draught Control
161	DR031	Draught Control Assy H3/C'man
162	DR031	Draught Control Assy H3/C'man
162	FF3001	M3 Washer Plain BZP
163	29551	Oil Valve Toby 5.5-17.5cc
164	DR031	Draught Control Assy H3/C'man
164	DR017	Control Cable Long 460mm
165	DR031	Draught Control Assy H3/C'man
165	DR010	Sub Frame Draught Stabilizer