

Nestor Martin Stanford 80 Oil Parts List

1.

1	35262	Loading Lid Cast Black H8 H34
1	39320	Loading Lid Satin Black H8 H34
2	40065	Protection Plate Load Lid H8
3	RO138	Rope Seal Set H8 Oil Gas 24 25
4	37699	Top Plate Cast S80 Oil
4	37701	Top Plate Satin Black S80 Oil
5	FF5004	M5 x 12 Pozi Pan BZP
6	40064	Protection Plate Top Plate H8
7	FF5001	M5 Washers Plain BZP
8	FF5000	M5 Nut Full BZP
9	FF5028	M5 Stud 50mm
10	37710	Halfmoon Blank Plate H8 H10
10	37708	Halfmoon Blank Plate H8 Cast
11	FF5005	M5 x 16 Pozi Pan BZP
12	37717	Side Panel R/H S80 S33 Oil
12	37719	Side Panel R/H S33 Satin Black
13	FF5033	M5 x 12 Pozi Pan S/Steel
13	MS078	Glass Seal Set H1 2 8 10 14
14	13479	Glass Retaining Clip Harmony
14	MS078	Glass Seal Set H1 2 8 10 14
15	31856	Glass Clip Support Seal
15	MS078	Glass Seal Set H1 2 8 10 14
16	FF5005	M5 x 16 Pozi Pan BZP
17	32827	Hinge Lower Door H5 H8
18	32723	Circlip Ash Pan Door
19	FF5000	M5 Nut Full BZP
20	26231	Washer Concave for Enamel Flue
21	FF5012	M5 x 16 Pozi CSK S/S
223	1848	Hinge Pin S50 S80 Furnace Door
23	37723	Door Lower S80 Cast Black
23	37725	Door Lower Satin Black S80
24	FF5024	Nut M5 Square
25	FF7501	Self Tapping Screw No.8 x3/8in
26	1622	Magnet H5 Lower Door
27	37763	Magnet Support Bracket H5
28	38547	Latching Pin Lower Door H5 S50
28	FF5000	M5 Nut Full BZP
29	39778	Latch Lower Door H5 S50

Woodman's Parts Plus
www.woodmanspartsplus.com

30	FF5006	M5 x 20 Pozi Pan BZP
31	38036	Door Furnace Cast S80 Bowed
31	38034	Door Furnace S80 Satin Black
32	RO138	Rope Seal Set H8 Oil Gas 24 25
33	MS078	Glass Seal Set H1 2 8 10 14
34	39653	Handle S23 S33 S80 Nickel
35	37942	Glass S80 Oil
36	37716	Side Panel LH Satin Blk S80
36	37714	Side Panel L/H S80 S33 Oil
37	37707	Front Panel S80 Cast Black
37	37705	Front Panel S80 Satin Black
2.		
38	14618	Screw Self Tap Hex Head
39	38488	Rear RH Heat Shield H8 Oil
40	3940	Wing Nut M5 Steel BZP
41	FF5000	M5 Nut Full BZP
42	FF5005	M5 x 16 Pozi Pan BZP
43	11390	Burner Gasket 6 and 8 Burner
44	RO1121	Rope 8mm dia Glass Fibre
45	14618	Screw Self Tap Hex Head
46	32875	Identification Plate H5 S50
47	23908	Catalyser Support 8 inch MK2
48	38685	Oil Burner 8 inch LH Inlet
49	26428	Catalyser 8 inch Mk2 Single
50	38500C	Igniter Kit Short Oil Stove
51	FF7701	Self Tapping Screw No12x3/8in
52	RO192	Flat S/A Rope Seal 500mm
53	26231	Washer Concave for Enamel Flue
54	FF5013	M5 x 20 Pozi CSK BZP
55	34452	Flue Spigot 4in Cast H5 H8 H10
55	38205	Flue Spigot 4in Satin Harmony
56	MS1013	Choke Flue H1 H2 H5
57	33585	Top Flue Adaptor H5 H8 H10 Oil
58	34285	Gasket Ceramic Top Flue
3.		
60	DR031	Draught Control Assy H3/C'man
60	DR010	Sub Frame Draught Stabilizer
61	DR031	Draught Control Assy H3/C'man
61	DR012	Spindle Cable Actuator
62	DR031	Draught Control Assy H3/C'man

Woodman's Parts Plus
www.woodmanspartsplus.com

62	DR021	Actuator Shaft End Cap
63	DR031	Draught Control Assy H3/C'man
63	DR011	Cam Draught Stabilizer
64	DR031	Draught Control Assy H3/C'man
64	DR015	Magnet Anisotropic Small
65	14618	Screw Self Tap Hex Head
66	33781	Baffle H8 Oil
67	33783	Stop Gap H5 Multifuel
68	DR031	Draught Control Assy H3/C'man
68	DR014	Magnet Anisotropic Large
69	17369	Breather Tube Oil Valve H5 S50
70	MS2110	Split Cotter Pin 1 1/4"x3/32
71	2805	Draught Stabilizer 5in al Efel
72	DR031	Draught Control Assy H3/C'man
72	DR017	Control Cable Long 460mm
73	39479	Rod Knob to Oil Valve H8
74	DR031	Draught Control Assy H3/C'man
74	FF3000	M3 Nut Full BZP
75	41109	Knob Oil Control MK3 H5 H8 H10
76	38536	Knob Oil Control Mk2
77	FF3500	M3.5 x 16 Pan Head M/C Screw
78	38489	Support Control Knob H8
79	14618	Screw Self Tap Hex Head
80	DR031	Draught Control Assy H3/C'man
80	FF3002	M3 Washer Spring
81	DR031	Draught Control Assy H3/C'man
81	DR013	Spring Return Mechanism
82	DR031	Draught Control Assy H3/C'man
82	FF3004	M3 x 10 Pozi Pan BZP
83	DR031	Draught Control Assy H3/C'man
83	DR019	Brass Channel Draught Control
84	FF3019	M3 x 8 mm Bolt Hex Head
85	29551	Oil Valve Toby 5.5-17.5cc
85	MS10062	Filter Gasket Toby Oil Valve
85	MS10061	O Ring Toby DVR Metering Stem
86	32782	Support Oil Valve H5 H8 H10
87	FF6008	M6 x 40 Pozi Pan BZP
88	FF6008	M6 x 40 Pozi Pan BZP
89	FF6001	M6 Washers Plain BZP
90	FF6000	M6 Nut Full BZP
91	40307	Pipe to Burner H8 Oil
91	1504	Nut Oil Connection

91	112	Olive
91	2734	Couplet Connection from Oil
92	DR031	Draught Control Assy H3/C'man
92	DR017	Control Cable Long 460mm
93	DR031	Draught Control Assy H3/C'man
93	DR018	Slide Bar Draught Control
94	DR031	Draught Control Assy H3/C'man
94	FF3019	M3 x 8 mm Bolt Hex Head
95	DR031	Draught Control Assy H3/C'man
95	FF3000	M3 Nut Full BZP
96	DR031	Draught Control Assy H3/C'man
96	FF3019	M3 x 8 mm Bolt Hex Head
4.		
97	CE102	Ceramic Coal Base Oil
97	CE101	Coal Set Loose for Oil
98	38955	Protection Plate Burner Oil
99	20194	Switch Less Button Ignition
100	MS1121	Transformer Kit all Models
101	14618	Screw Self Tap Hex Head
102	31756	Power Cord Oil Stove UK Spec
103	37720	Foot Cast S33
103	37722	Foot S80 Satin Black
104	35268	Base Plate H8 Gas
105	32803	Log Guard H5 Oil/Gas [P]
106	26687	Tube Draught Test H5 S50 Oil
107	38093	Floor Protection Plate H8 Oil
108	FF5020	M5 x 20 Hex Head Set Screw BZP
109	38099	Plinth H8 S80 H31
109	38101	Plinth H8,S80 H31 Satin Black
110	RO1261	Rope 12mm dia Glass Fibre per
111	27078	Grub Screw for Foot Adjustment
112	5632	Foot Spacer (under foot)
113	MS38548	Glove Red Leather Pair
114	FF8000	M8 Nut Full BZP
115	FF8001	M8 Washers Plain BZP
116	FF8013	M8 x 30 Hex Head Set Screw BZP
117	20019	Tool Riddling and Lifting
118	40785	Paint Spray Cast Black Stove
118	60429	Paint Spray Insert Black
119	27440	Touch Up Satin Black