

Efel Toledo Oil Parts List

<b>1.</b>		
1	6139	Handle Furnace Door Toledo
2	31587	Glass Seal Set Toledo Gas Oil
3	31587	Glass Seal Set Toledo Gas Oil
4	15894	Glass Strips Complete Toledo
5	5771	Glass Retaining Strip Toledo
6	5716	Side Panel Toledo Oil Right
7	5715	Side Panel Toledo Left
8	6521	Front Cast Iron Toledo Oil/Gas
9	5767	Loading Lid Montana/Toledo
10	6480	Base Plate Toledo Oil
11	5645	Top Plate Cast Black Toledo
12	6523	Burner Base Plinth
13	6524	Fire Box Rear H1 Toledo Oil
14	6103	Position Indicator Oil Knob
15	6525	Heat Shield Rear
16	6526	Toledo Panel
17	6520	Drip Tray
18	6105	Heat Shield Panel Oil Valve
19	6471	Recuperator Front Toledo
20	3113	Catalyser Support Ring 6 inch
21	RO1121	Rope 8mm dia Glass Fibre
22	RO1121	Rope 8mm dia Glass Fibre
23	5796	Flue Spigot Cast Black Toledo
24	13976	Badge (Efel)
25	MS001	Knob Complete for Oil Stoves
26	32807	Oil Valve Toby 4-12 cc
27	6470	Base Plate Support Toledo
28	199	Burner 6 inch Pot Mk1
29	RO1121	Rope 8mm dia Glass Fibre
31	26452	Oil Valve CI 4-12cc Kerosene
31	32807	Oil Valve Toby 4-12 cc
32	2805	Draught Stabilizer 5in al Efel
33	13710	Eccentric Screw Toledo Ash Pan
34	13710	Eccentric Screw Toledo Ash Pan
36	13841	Pipe to Burner
36	1504	Nut Oil Connection
36	112	Olive
37	28821	Decoking Assembly to Burner
39	6079	Tie Rod 6mm x 595mm

40	337	Catalyser 6 inch Mk1
41	16149	Decoking Assembly
42	MS999	No Part Number Listed
44	40785	Paint Spray Cast Black Stove
44	60429	Paint Spray Insert Black
46	5712	Glass Panel Toledo Coal/Gas
47	20019	Tool Riddling and Lifting
49	5665	Foot Montana/Toldeo/Bastogne
50	15771	Glass Retaining Strip Toledo
52	5635	Hinge Toledo, Montana, Giant
54	6141	Door Handle Ash Pan Toledo
55	6140	Ash Pan Door Toledo
56	6138	Door Furnace Front Toledo
57	RO144	Rope Seal Set Toledo Oil
58	6091	Hinge Rod Toledo Montana
59	6092	Hinge Rod Ash Pan Door Montana
60	5630	Hinge End Nut Toledo Montana
61	MS38548	Glove Red Leather Pair
62	6088	Foot Fixing Plate
62	FF8001	M8 Washers Plain BZP
62	FF8000	M8 Nut Full BZP
63	5629	Hinge Pin Toledo Montana
65	5632	Foot Spacer (under foot)
66	6462	Screw Glass Retaining Washer
74	14932	Glass Strip Toledo Centre

**2.**

6	5716	Side Panel Toledo Oil Right
7	5715	Side Panel Toledo Left
8	6521	Front Cast Iron Toledo Oil/Gas
9	5767	Loading Lid Montana/Toledo
10	6480	Base Plate Toledo Oil
11	5645	Top Plate Cast Black Toledo
12	6523	Burner Base Plinth
13	6524	Fire Box Rear H1 Toledo Oil
14	6103	Position Indicator Oil Knob
15	6525	Heat Shield Rear
16	6526	Toledo Panel
17	6520	Drip Tray
18	6105	Heat Shield Panel Oil Valve
19	6471	Recuperator Front Toledo
20	3113	Catalyser Support Ring 6 inch

Woodman's Parts Plus  
[www.woodmanspartsplus.com](http://www.woodmanspartsplus.com)

21	RO1121	Rope 8mm dia Glass Fibre
22	RO1121	Rope 8mm dia Glass Fibre
23	5796	Flue Spigot Cast Black Toledo
24	13976	Badge (Efel)
25	MS001	Knob Complete for Oil Stoves
26	32807	Oil Valve Toby 4-12 cc
27	6470	Base Plate Support Toledo
28	199	Burner 6 inch Pot Mk1
29	RO1121	Rope 8mm dia Glass Fibre
31	26452	Oil Valve CI 4-12cc Kerosene
31	32807	Oil Valve Toby 4-12 cc
32	2805	Draught Stabilizer 5in al Feel
33	13710	Eccentric Screw Toldeo Ash Pan
34	13710	Eccentric Screw Toldeo Ash Pan
36	13841	Pipe to Burner
36	1504	Nut Oil Connection
36	112	Olive
37	28821	Decoking Assembly to Burner
39	6079	Tie Rod 6mm x 595mm
40	337	Catalyser 6 inch Mk1
41	16149	Decoking Assembly
42	MS999	No Part Number Listed
44	40785	Paint Spray Cast Black Stove
44	60429	Paint Spray Insert Black
46	5712	Glass Panel Toledo Coal/Gas
47	20019	Tool Riddling and Lifting
49	5665	Foot Montana/Toldeo/Bastogne
50	15771	Glass Retaining Strip Toledo
52	5635	Hinge Toledo, Montana, Giant
54	6141	Door Handle Ash Pan Toledo
55	6140	Ash Pan Door Toledo
56	6138	Door Furnace Front Toledo
57	RO144	Rope Seal Set Toledo Oil
58	6091	Hinge Rod Toledo Montana
59	6092	Hinge Rod Ash Pan Door Montana
60	5630	Hinge End Nut Toledo Montana
61	MS38548	Glove Red Leather Pair