

Napoleon Ascent B30 Part List

12.

REF. NO.	PART NUMBER	DESCRIPTION
1	W565-0154	SAFETY SCREEN
2	W010-3246	SAFETY SCREEN ASSEMBLY
3	W715-0976	TOP FINISHING TRIM
4	W335-0067	HOOD
5	W385-0334	NAPOLEON LOGO
6	W010-3244	DOOR ASSEMBLY
7	W350-0342	BATTERY HOUSING

REF. NO.	PART NUMBER	DESCRIPTION
8	W655-0522	LOG SUPPORT
9	W350-0126	ELECTRICAL BOX
10	W350-0701	PILOT HOUSING
11	W010-3070	DOOR LATCHES (X4)
12	W570-0135	SHOULDER SCREWS (X4)
13	W635-0078	STAND-OFFS (X2)

13.

REF. NO.	PART NUMBER	DESCRIPTION
1	W430-0003	MAGNETS (X12) (TK30)
2	W715-0977	TOP TRIM (TK30)
3	W715-0952	SIDE TRIMS (X2) (TK30)
4	W475-0940	SIDE PORCELAIN PANELS (X2) (PRPB30)
5	W475-0939	REAR PORCELAIN PANEL (PRPB30)
6	W135-0578	LEFT CROSSOVER LOG (GL-694)
7	W135-0575	REAR LOG (GL-694)
8	W135-0579	RIGHT CROSSOVER LOG (GL-694)
9	W135-0576	LEFT SIDE LOG (GL-694)

REF. NO.	PART NUMBER	DESCRIPTION
10	W135-0577	RIGHT SIDE LOG (GL-694)
11	W361-0016	GLOWING EMBERS
12	W010-3281	ZEN DECORATIVE FRONT (Z30F)
13	W010-3282	HERRITAGE DECORATIVE FRONT (H30F)
14	W690-0002	THERMIDISC (EP35)
15	W080-1335	THERMAL DISK BRACKET (EP35)
16	W062-0051	BLOWER (EP35)
17	W500-0746	BLOWER MOUNTING PLATE (EP35)
18	W290-0128	VIBRATION DAMPER GASKET (EP35)

14.

REF. NO.	PART NUMBER	DESCRIPTION
1	W100-0162	BURNER ASSEMBLY
2	W035-0353	BURNER BASE
3	W290-0248	VALVE TRAIN GASKET
4	W190-0022	CONTROL BOARD
5	W707-0002	TRANSFORMER
6	W290-0095	AIR HOUSING GASKET
7	W500-0276	VENTURI HOUSING COVER PLATE
8	W350-0311	VENTURI HOUSING
9	W290-0102	VENTURI GASKET
10	W235-0046	3/8" ELBOW
11	W456-0044	BURNER ORIFICE #44 (NG)
12	W456-0055	BURNER ORIFICE #55 (LP)

REF. NO.	PART NUMBER	DESCRIPTION
13	W450-0036	PAL NUT
14	W432-0046	3/8" MANIFOLD
15	W750-0309	WIRE HARNESS ASSEMBLY
16	W010-3121	PILOT ASSEMBLY (NG)
17	W010-3252	PILOT ASSEMBLY (LP)
18	W290-0029	PILOT GASKET
19	W750-0193	THERMOSTAT WIRE
20	W080-1402	VALVE BRACKET
21	W725-0070	VALVE (NG)
22	W725-0073	VALVE (LP)

15.

REF. NO.	PART NUMBER	DESCRIPTION
1	W100-0162	BURNER ASSEMBLY
2	W035-0353	BURNER BASE
3	W290-0248	VALVE TRAIN GASKET
4	W080-1339	IGNITER BRACKET
5	W357-0001	PUSH BUTTON START
6	W290-0095	AIR HOUSING GASKET
7	W500-0276	VENTURI HOUSING COVER PLATE
8	W350-0311	VENTURI HOUSING
9	W290-0102	VENTURI GASKET
10	W235-0046	3/8" ELBOW
11	W456-0044	BURNER ORIFICE #44 (NG)
12	W456-0055	BURNER ORIFICE #55 (LP)

REF. NO.	PART NUMBER	DESCRIPTION
13	W450-0036	PAL NUT
14	W432-0078	FLEX MANIFOLD
15	W750-0193	WIRE ASSEMBLY
16	W010-3121	PILOT ASSEMBLY (NG)
17	W010-3252	PILOT ASSEMBLY (LP)
18	W290-0029	PILOT GASKET
19	W080-1426	VALVE BRACKET
20	W725-0025	VALVE (NG)
21	W725-0043	VALVE (LP)