

Burner Assemblies

HA-30-00230	SITS valve assembly - NG (2003 - current)
HA-30-00034	Honeywell valve assembly - NG (2000 - 2004)
HA-30-00015	Valve assembly - Robertshaw - NG - (1997 - 1999)
HA-30-00016	Valve assembly - Robertshaw - LP (1997 - 1999)
05-02-00313	Gas valve - S.I.T. 225 degree - NG (2003 - current)
05-02-00282	Gas valve - S.I.T. - LP (never available)
05-02-00293	Honeywell gas valve - NG (2000 - 2004)
05-02-00270	Robertshaw gas valve - NG - (1997 - 1999)
05-02-00271	Robertshaw gas valve - LP (1997 - 1999)
HA-30-00386	Heavy Duty SIT NG to LP Conversion Kit (2003 - current)
HA-30-00044	LP Conversion Kit for Honeywell Valve (2000 - 2004)
05-02-00314	LP Hi/Low Regulator SIT valve (2003 - current)
05-02-00289	NG Hi/Low Regulator SIT valve (2003 - current)
05-02-00301	NG Blue Screw Plug - Honeywell valve only (2000 - 2004)
05-02-00294	LP Red Screw Plug - Honeywell valve only (2000 - 2004)
05-02-00237	Hi/Lo Regulator Knob NG - Robertshaw (1997 - 2000)
05-02-00236	Hi/Lo Regulator Knob LP - Robertshaw (1997 - 2000)
65-14-00032	Main orifice (NG) #32 (1997 - current)
65-14-00050	Main orifice (LP) #50 (1997 - current)
65-03-00022	Blank Orifice
05-04-00035	NG Pilot assembly, complete (NG) (1997 - current)
HA-30-00470	LP Pilot Assembly with Hi-Temp LP Thermocouple (1997 - current)
05-07-00084	Hi-Temp LP Thermocouple (1997 - current)
05-07-00067	NG Thermocouple (1997 - current)
05-07-00061	Thermopile (1997 - current)
HA-41-00197	Pilot Shield - All models
05-04-00038	Pilot orifice NG (PSE) .025 (2000 - current)
05-04-00036	Pilot orifice LP (PSE) .014 (2000 - current)
55-02-00072	Pilot Gas Tube (1997 - current)
05-04-00033	Pilot assembly complete NG (HW mfg.)
05-04-00034	Pilot assembly complete LP (HW mfg.)
65-03-00023	Pilot orifice (NG) .028 (HW mfg.) (1997 - 1999)
65-03-00027	Pilot orifice (LP) .016 (HW mfg.) (1997 - 1999)
HA-30-00088	Burner tube weldment (2001 - current)
HA-30-00332	LP Burner tube weldment (2001 - current) ** SEE REMARKS **
HA-30-00331	LP Burner tube weldment (1997 - 2001) ** SEE REMARKS **
HA-30-00009	Burner tube weldment without log supports (1997 - 2001)
HA-30-00323	Burner tube weldment with log supports (1997 - 2001)
55-02-00069	Gas Supply FlexTube 13" (2003 - current)

Part Number	Description
Burner Assemblies - Continued	
65-07-00020	3/8" Compression Nut (2 required per Gas Supply Flex Tube)
65-07-00021	3/8" Compression Ferrells (2 required per Gas Supply Flex Tube)
65-07-00010	Brass Elbow that orifices attached to - 3/8" tube x 1/8" elbow
05-01-00154	Hi-limit switch
65-02-00098	Gasket for Valve Assembly (2003 - current)
Door Assemblies	
HA-30-00012	Door Assembly Flat (includes glass and frame)
65-06-00463	Glass - flat
65-02-00093	Flat Gasket for between Glass Frame & Glass
HA-30-00040	Door Assembly Bay (includes bay glass and frame)
65-06-00623	Glass - bay
65-02-00055	Tadpole Door Gasket (Sold by the foot)
HA-30-00014	Bottom Spring Door Catch Assembly
65-06-00425	Springs for Catch Assembly
HA-29-00031	3-Tab Door Catch
Logs & Firebrick	
35-01-00268	Timberfire Log (2001 - current) (Previously AA-11-00623)
35-01-00348	Timberfire Left Rear Log #1
35-01-00350	Timberfire Right Mid Log #2
35-01-00351	Timberfire Top Mid Log #3
35-01-00349	Timberfire Left Mid Log #4
35-01-00353	Timberfire Right Rear Log #5
35-01-00352	Timberfire Right Combo Log #6
AA-11-00714	DeepTimber Log Conversion Kit (2003 - 2004)
AA-11-00526	TimberfireConvKit-Logs, Burner & Airbox (2001 - 2004)
35-01-00226	Log Set 1 piece 24"
35-01-00241	Random log set 24" (1997 - 2001) - One Piece Logset
35-01-00383	Antique Red Fire Brick Set w/Baffle Brick (2005 - current)
HA-29-00351	Brick Clip to support Baffle Brick #35-01-00383
35-01-00275	Antique Red Fire Brick Set (2001 - 2006)(Previously AA-11-00619)
35-01-00280	Antique Red - Bay Fire Brick (2001 - current)
35-01-00225	Firebrick kit (1997 - 2001) - TAN Brick
35-01-00253	Firebrick - bay floor (1997 - 2001)
35-01-00240	Coals 12 oz. Bag
35-01-00422	Glowing Inswool #5
35-01-00239	Glowing Inswool 6 oz bag
AA-11-00875	Brick / Log Touch Up Paint Kit

Part Number	Description
Blower Assemblies	
15-02-00083	Blower Kit (2008 - current) w/Molex Wiring Harness
15-02-00064	RH Blower w/motor (2001 - current) BLUE LABEL
15-02-00065	LH Blower w/motor (2001 - current) WHITE LABEL
10-01-00003	Rheostat
10-01-00047	Knob for Rheostat
05-01-00157	Thermo-disc (snap-disc)
10-03-00119	Wiring harness with Molex connector
10-03-00080	Molex Connector Jumper Block End
15-02-00062	Blower Kit (2001 - 2008)-Replace with 15-02-00064 & 15-02-00065 blowers
15-02-00051	Blower w/motor (1997 - 2001) (Squirrel cage 11 3/4" long)
05-01-00191	Magnetic Thermo-disc bracket assembly
Miscellaneous	
AA-11-00645	DXV35 Rear Vent Starter Collar Kit with Plug Plates
AA-11-00803	DXV35 Conversion Kit Rear Vent Back to Top Vent
HA-42-00195	Piezo Igniter Push Button Retro Kit(2008 - current)
65-06-00149	Piezo igniter (standard) (1997 - 1999) (2003 - 2008)
65-06-00626	Piezo igniter (Honeywell valve) (2000 - 2004)
65-07-00741	Flexible Gas Connector with Valve 3/8"x18" (2003 - current)
65-07-00743	3/8" MPT x 3/8" Flare Fitting to go into inlet side of valve
65-07-00744	1/2" FPT x 3/8" Flare with Ball Gas Valve
05-02-00295	On/Off extension knob Honeywell for bay units (2000 - 2003)
05-02-00296	Piezo extension knob Honeywell for bay units (2000 - 2003)
05-02-00297	Hi/low extension knob Honeywell for bay units (2000 - 2003)
65-06-01049	Black Touch up paint for all Powder Coat finishes (1997 - current) Krylon
65-06-01055	Black Touch up paint for Fireplace Body / Door (1997 - current)
65-06-00266	Deerfield Touch-up Paint (Charcoal Stove Bright)
65-06-00909	Mill Pack Sealant (For use with Caulking Gun)
65-06-00455	Kel-Kem glass polish
65-06-00367	Magnet (1)
HA-19-00073	Magnet Bracket(1)
65-06-00372	Door Hinge(1 pair) (lower hinges mounted to fireplace)
HA-19-00065	Door Hinge mounting bracket for lower hinges mounted to fplace
HA-30-00195	Grate (2003 - current)
HA-30-00010	Grate - (2003 & Before)
HA-30-00074	Airbox (2001 - current)
HA-30-00624	Airbox (1997 - 2001)
HA-29-00033	Baffle (1997 - current)
HA-30-00611	Faceplate Black- Complete w/brackets
65-06-00357	Exhaust Starter Pipe
65-02-00058	Top Vent Gasket - For Intake Air Gasket, Top Vent Only
65-02-00094	Top Vent Gasket - For Exhaust Gasket, Top Vent Only
65-02-00095	Rear Vent Gasket - For Intake Air Gasket, Rear Vent Only
65-02-00096	Rear Vent Gasket - For Exhaust Gasket, Rear Vent Only
HA-29-00353	Nailing Flange-EACH
HA-20-00034	Electrical Junction Box (2"x4" box that mounts on left side)
10-07-00040	Speaker Block - Discontinued on all Models after 2-2004
HA-42-00084	Damper System Rod Assembly - Must also order HA-30-00193
HA-30-00193	Damper System Plate - Must also order HA-42-00084