

Harman Exception F200 Insert Parts List

1)	BODY WELDMENT	1-89-09102
2)	DAMPER ARM COVER	2-00-34133
3)	DAMPER LINK	2-00-34120
4)	WOODEN KNOB	3-40-05662
5)	LEFT SIDE COVER	2-00-34127
6)	AIRSLIDE	2-00-34113
7)	HCS 1/4-20 X 7/8	3-30-1252008713
8)	3/8OD X 1/2" BUSHING	3-50-05229
9)	AIR ADJUSTER	1-10-34112
10)	5/16" COIL SPRING	3-40-00088
11)	AFTERBURNER	3-40-05171
12)	DAMPER AND FRAME	1-10-08060
13)	LEFT SIDE PLATE	1-10-08058
14)	HOOD GLASS CLIPS	2-00-07071-1/2
15)	RAMP	1-10-08111
16)	AFTERBURNER GLASS	3-40-05180
17)	AFTERBURNER HOOD	1-10-08200
18)	RIGHT SIDE PLATE	1-10-08059
19)	PAW BOLT	4-31-08055
20)	BRASS ELBOW	3-40-00121
21)	SSS 5/16-18 X 1/4	3-30-2931180252
22)	WOODEN HANDLE	3-40-00122
23)	RPH MS 1/4-20 X 2-1/2	3-30-625202501
24)	GOLD DOOR W/ROPE	1-10-05165
	CAST DOOR W/ROPE	1-10-08159A
25)	GLASS WITH GASKET	1-10-08056
26)	3/8 X 1-7/8 DOOR PIN	4-30-00138-2
27)	GLASS CLIPS	2-00-05202
	GLASS BOLTS	3-30-5110240382
28)	ASH LIP TRIM	3-43-34001
29)	ASH LIP	2-00-34105
30)	FRONT BASE COVER	2-00-34122
31)	BLOWER	3-21-02524
32)	AIRSLIDE COVER	2-00-34121
33)	ANDIRONS	2-00-05222
34)	POWER CORD W/VSC	3-20-06652
35)	FULL BRICK	3-40-900450125
36)	2-1/8" BRICK	4-40-08115
37)	ANGLE CUT BRICK	4-40-08113
38)	RIGHT SIDE COVER	2-00-34128
39)	AIR GRILL TRIM	3-43-34119
40)	TOP WING	1-10-34126
41)	LEFT WING	1-10-34124
42)	1/4" GLASS GASKET	3-44-11862 (5')
43)	DAMPER WELDMENT	1-10-08077
44)	RIGHT WING	1-10-34125