

Hampton HI300 Parts List

**MAIN ASSEMBLY**

Part #	Description	Not Shown in the drawing:
1) 942-681* 936-238	Right Side Cast Side Cast Gasket	300-981* Cast Grill
2) 300-021	Flange Adaptor	948-137 Small Spring Handle Nickel
3) 942-691*	Ashlip	910-142 Fan Thermodisc
4) 300-006	Fan Clip	910-138 2 Way Switch
6) 942-671* 936-238	Left Side Cast Side Cast Gasket	910-140 3 Way Switch
8) 942-661*	Mantel Top	948-220 Hampton Logo Plate
15) 300-911*	Fan Assembly	910-678 120 Volt Power Cord
20) 300-571*	Door Assembly	300-513 Upper Door Hinge Assembly
21) 948-179 948-178	Wooden Handle Black Wooden Handle Dark Brown	948-155 Bottom Door Hinge Pin
22) 300-551	Door Latch	* Last digit of part number represents color: 1 = Metallic Black, 5 = Timberline Brown,
23) 940-370/P 846-570	Door Glass Door Gasket Kit	
24) 936-238	Glass Retainer Glass Gasket (sold per ft.)	
36) 033-953	Air Tube 3/4" (Qty:4)	
37) 020-957	Baffle (2/set)	
38) 820-482	Smoke Deflector	
40) 910-157/P	Fan Motor Only	

**STANDARD CAST FACEPLATE**

Part #	Description
300-921	Cast Faceplate - Metallic Black
300-925	Cast Faceplate - Timberline Brown
200) *	Top Faceplate
201) *	Left Side Faceplate
202) *	Right Side Faceplate

\* Not available as a replacement part.

**OVERSIZE CAST FACEPLATE**

Part #	Description
300-971	Oversize Cast Faceplate - Metallic Black
300-975	Cast Faceplate - Timberline Brown
300) *	Top Faceplate
301) *	Left Side Faceplate
302) *	Right Side Faceplate
303) 300-060	Mounting Plate LH
305) 300-061	Mounting Plate RH

**Not Shown in the Drawing**  
300-005 Top Retainer

\* Not available as a replacement part.

**BRICK PANELS**

Part #	Description
180-960	Brick Set - Complete