

3.6 Parts list for model Morsø 3112B & 3142B

Pos. No.	Parts	3142B	3112B
1	Base plate	443145xx	443156xx
2	Front frame	443146xx	443146xx
3	Door	443124xx	443124xx
4	Air valve	443104xx	443104xx
5	Side plate	443154XX	443118xx
6	Rear plate, cast iron	443141xx	443141xx
7	Intermediate frame	34310800	34310800
8	Riddling grate	44310900	44310900
9	Baffle plate, cast iron	44313500	44313500
10	Top plate konv.	443142xx	443142xx
11	Access Door	34313600	34313600
12	Flue collar	441459xx	441459xx
13	Cover	441410xx	441410xx
14	Rear plate	543146xx	543146xx
15	Radiant shielding, bottom	54312700	54312700
16	Ash tray	54310100	54310100
17	Riddling arm	71313900	71313900
18	Axis for handle	75462700	75462700
19	Glass fitting	54146361	54146361
20	Fitting for flue collar	44256700	44256700
21	Bush, brass	752621	752621
22	Baffle plate, stainless	71312300	71312300
23	Door handle	752625	752625
24	Shaking handle	44262021	44262021
25	Ceramic glass	79310000	79310000
26	Stone, side	79311300	79311300
27	Stone, back	79311400	79311400
28	Glass gasket	79074500	79074500
29	Black steel set screw	731608	731608
30	Black steel set screw	731620	731620
31	Screw	743625	743625
32	Steel box nut	735006	735006
33	Washer	791891	791891
34	Washer	746006	746006
35	Pinol screw	739405	739405
36	Screw	73850800	73850800
37	Hinge pin	54503100	54503100
38	Hinge pin	542056	542056
39	Screw	74163504	74163504
40	Black steel set screw	731820	731820
41	Black steel set screw	731625	731625
42	Washer	79189300	79189300
43	Hinge pin	74701000	74701000
44	Baffle plate, upper	34313400	34313400
45	Inside top plate	34313300	34313300

3.6 Parts list for model Morsø 3112B & 3142B

Pos. No.	Parts	3142 B	3112 B
46	Distance tube	54313100	54313100
47	Distance tube	54345500	54345500
48	Fitting for reg.	71346500	71346500
49	Draught Control	71316000	71316000
50	Air inlet arm	71346400	71346400
51	Handle for air inlet arm	75180400	75180400
52	Knob for riddling grate	752620	752620
53	Cotter pin	74202000	74202000
54	Washer	736106	736106
55	Screw	731610	731610
56	Steel box nut	735008	735008
57	Stainless pressure spring	79048600	79048600
58	Washer	79189400	79189400
59	Screw	73960800	73960800
60	Screw	731635	731635
61	Screw	731630	731630
62	Screw	791835	791835
63	Screw	73861700	73861700
64	Airtightbox	71313800	71313800
65	Air Duct, back	443143xx	443143xx
66	Screw	731616	731616
67	Air Tight Adapter	71360600	71360600
68	Washer	79190000	79190000
69	Fitting without thread f. cover	44256800	44256800
70	Screw	731650	731650
71	Black steel set screw	731820	731820
72	Leg	443407xx	443407xx
73	Spring	79048800	79048800
74	Steel box nut	73520800	73520800
75	Poker	541075	541075
76	Plate for reducing air	71315700	71315700
77	Screw	731608	731608
78	Screw	79183600	79183600
79	Pinol Screw	739405	739405
80	Lock ring	791824	791824
81	Washer	746105	746105
82	Push-on Washer	746206	746206
83	Side plate convection	443117xx	-
84	Washer	79189400	-
85	Pinol screw	739640	-
86	Distance tube	545003	-