

Vermont Castings LHEDV Series Part List

LHEDV Series (continued)

| Ref. | Description | LHERDV20 | LHECDV20 | LHERDV30 | LHECDV30 |
|------|---------------------------------------------|-----------------------------------|-----------------|-----------------|-----------------|
| 1. | Log Set Complete | 10005332 | 10005332 | 10004866 | 10004866 |
| 1a. | Log Rear Left | 10005333 (JR7) | 10005333 (JR7) | 10004874 (KR22) | 10004874 (KR22) |
| 1b. | Log Rear Right | 10005334 (JR8) | 10005334 (JR8) | 10004875 (KR23) | 10004875 (KR23) |
| 1c. | Log Rear Center | - | - | 10004876 (KR24) | 10004876 (KR24) |
| 1d. | Log Front Left | 10005335 (JR9) | 10005335 (JR9) | 10004878 (KR25) | 10004878 (KR25) |
| 1e. | Log Front Right | 10005336 (JR10) | 10005336 (JR10) | 10004879 (KR26) | 10004879 (KR26) |
| 2. | Lava Rock Burner Package | 57897 | 57897 | 57897 | 57897 |
| 3. | Lava Rock Package | - | - | 10001454 | 10001454 |
| 4. | Burner Housing Assembly with Tiles | 10005294 | 10005294 | 10004972 | 10004972 |
| 5. | Ceramic Tile (Single) | 57803 | 57803 | 57803 | 57803 |
| 6a. | Orifice Front Burner (Nat.) | See Rating Plate for Orifice Size | | | |
| 6b. | Orifice Front Burner (Prop.) | See Rating Plate for Orifice Size | | | |
| 7a. | Orifice Rear Burner (Nat.) | See Rating Plate for Orifice Size | | | |
| 7b. | Orifice Rear Burner (Prop.) | See Rating Plate for Orifice Size | | | |
| 8a. | Orifice Pilot SIT Top Convertible | 10002268 | 10002268 | 10002268 | 10002268 |
| 8b. | Orifice Pilot SIT Top Convertible | 10002269 | 10002269 | 10002269 | 10002269 |
| 9a. | Orifice Pilot PSE (Nat.) | 10001822 | 10001822 | 10001822 | 10001822 |
| 9b. | Orifice Pilot PSE (Prop.) | 10001823 | 10001823 | 10001823 | 10001823 |
| 10a. | Pilot Assembly SIT Top Convertible (Nat.) | 10002264 | 10002264 | 10002264 | 10002264 |
| 10b. | Pilot Assembly SIT Top Convertible (Prop.) | 10002265 | 10002265 | 10002265 | 10002265 |
| 11a. | Pilot Assembly PSE (Nat.) | 10001741 | 10001741 | 10001741 | 10001741 |
| 11b. | Pilot Assembly PSE (Prop.) | 10001742 | 10001742 | 10001742 | 10001742 |
| 12a. | Pilot Assembly RFN (Nat.) | - | 20002266 | - | 20002266 |
| 12b. | Pilot Assembly RFP (Prop.) | - | 20002268 | - | 20002268 |
| 13a. | Pilot Orifice RFN (Nat.) | - | 20000908 | - | 20000908 |
| 13b. | Pilot Orifice RFP (Prop.) | - | 20000907 | - | 20000907 |
| 14. | Pilot Tubing w/Fittings | 10001296 | 10001296 | 10001296 | 10001296 |
| 15. | Manifold Tubing w/Fittings | 57318 | 57318 | 57318 | 57318 |
| 16. | Thermocouple SIT | 53373 | 53373 | 53373 | 53373 |
| 17. | Thermocouple PSE | 10001825 | 10001825 | 10001825 | 10001825 |
| 18. | Thermopile | 51827 | 51827 | 51827 | 51827 |
| 19. | Electrode Ignitor w/Cable SIT | 10001297 | 10001297 | 10001297 | 10001297 |
| 20. | Ignitor Piezo SIT | 52464 | 52464 | 52464 | 52464 |
| 21. | Ignitor Piezo Honeywell | 20000062 | 20000062 | 20000062 | 20000062 |
| 22a. | Valve SIT 820 RN | 52677 | 52677 | 52677 | 52677 |
| 22b. | Valve SIT 820 RP | 52678 | 52678 | 52678 | 52678 |
| 23a. | Valve Honeywell RN | 10001782 | 10001782 | 10001782 | 10001782 |
| 23b. | Valve Honeywell RP | 10001759 | 10001759 | 10001759 | 10001759 |
| 24a. | Valve Honeywell RFN | - | 20003719 | - | 20003719 |
| 24b. | Valve Honeywell RFP | - | 20003720 | - | 20003720 |
| 25. | Antennae (for RFN or RFP Units) | - | 20003561 | - | 20003561 |
| 26. | Transmitter (for RFN or RFP Units) | - | 20002047 | - | 20002047 |
| 27. | Thermopile (for RFN or RFP Units) | - | 20002400 | - | 20002400 |
| 28. | Cord Set (for RFN or RFP Units) | - | 20002541 | - | 20002541 |
| 29. | Cord Set (for RN or RP Units) | 51865 | 51865 | 51865 | 51865 |
| 30. | Fan with Bracket | - | 54103 | - | 54103 |
| 31. | Fan Temperature Sensor (for RN or RP Units) | - | 51704 | - | 51704 |
| 32. | Speed Control Switch (for RN or RP Units) | - | 51738 | - | 51738 |
| 33. | Speed Control Knob (for RN or RP Units) | - | 51882 | - | 51882 |

LHEDV Series (continued)

| Ref. | Description | LHERDV20 | LHECDV20 | LHERDV30 | LHECDV30 |
|------|---------------------------------------------------------|----------|----------|----------|----------|
| 34. | Glass with Gasket | 10005297 | 10005066 | 10006888 | 10004870 |
| 35. | Gasket Glass | 57317 | 57317 | 57317 | 57317 |
| 36. | Frame Window | 10005295 | 10005067 | 10006887 | 10004873 |
| 37. | Remote Switch (for RN or RP Units) | 53606 | 53606 | 53606 | 53606 |
| 38. | Remote Wire Harness w/Terminals (for RN or RP Units) | 10002582 | 10002582 | 10002582 | 10002582 |
| 39. | Ceramic Fiber Brick FP (Optional) | JT1TR0 | JT1TC0 | KT1TR0 | KT1TC0 |
| 40. | Gasket Fan Cover | - | - | - | 10003486 |
| 41. | Flexible Connector (6") | 10005098 | 10005098 | 10005098 | 10005098 |
| 42. | Bracket Rear Log Assembly | 10005370 | 10005369 | 10004886 | 10004886 |
| 43. | Bracket Log Support Assembly | - | - | 10004885 | 10004885 |
| 44. | Gasket Cover Gas Line Access | 10004227 | 10004227 | 10004227 | 10004227 |
| 45. | Bracket Support Grate | - | - | 10003479 | 10003479 |
| 46. | Hinge 2 Springs | 52356 | 52356 | 52356 | 52356 |
| 47. | Shield Heat Pilot | 10000248 | 10000248 | 10000248 | 10000248 |
| 48. | Plate Relief with Gasket | 10002032 | 10002032 | 10002032 | 10002032 |
| 49. | Grate Assembly Flat Black | 10004967 | 10004967 | 10003478 | 10003478 |
| 50. | Plate Relief with Gasket Assembly (Burner Tray) | - | - | 10004192 | 10004192 |
| 51. | Bracket ON/OFF Switch | 10005035 | 10005035 | 10005035 | 10005035 |