

## Parts List

### Radiance Vent Free Gas Heater RUV40

1. Grille	130-1192	46. Front	130-1229
2. Grille Screen	160-1933	47. Cable, Control Door	160-1924
3. Top	130-1186	48. Spring, Control Door	120-1842
4. End, Left	130-1234	49. Control Door	130-1220
5. End, Right	130-1189	50. Control Door Handle, wood	160-0660
6. Rear Shroud, Outer	2000-0862	Handle Stub	160-1981
7. Duct Cap	2000-0875	51. Damper Tab (4)	160-1488
8. Duct Base	2000-0876	52. 1/4-20 x 3/8" Phillips Screw	120-0993
9. Heat Shield	2000-0877	53. 1/4-20 x 1/2" Hex Head Screw (5)	120-1338
10. Flue Collector	2000-0858	54. 1/4-20 x 1 1/4" Stud, top plate (4)	120-4212
11. Right Latch Bracket	2000-0859	55. Flat Washer	120-2470
12. Left Latch Bracket	2000-0860	56. 1/4-20 x Hex nut , Top to Sides (4)	120-3210
13. Back Log Bracket	2000-0991	57. Flat Washer, 1/4", Spring / Front	120-2474
14. Right Log Bracket	140-9173	58. 1/4-20 x 1" Leg Levelling bolt (4)	120-1745
15. Left Log Bracket	3000-0109	59. 1/4-20 x 3/8" Blk (4)	120-0993
16. Screen/Glass Frame Latch, 2	160-1992	60. #10 x 1/2" Pan Hd sheet metal screw	120-2058
17. Screen Frame Assembly	2000-0883	61. 8-32 x 2" Rnd Hd slotted screw	120-1243
18. Switch Box	140-8791	62. Catalyst	3000-0506
19. Switch, ON/OFF/T'STAT	160-1597	63. Glass	160-1290
20. Rheostat Plug	160-0561	64. Glass Gasket (7")	120-3702
21. Wire Clip	120-8618		
22. Wire Tie, wire harness/rear shroud	120-1504		
23. Wire Harness, Burner/Thermostat	160-1913		
24. Wire Harness, Snapstat extension	3000-0453		
25. Gas Log Set	2000-0853		
26. Back Log	2000-0856		
27. Right Middle Log	2000-0854		
28. Left Middle Log	2000-0855		
29. Top Log	3000-0037		
30. Left Front Ember Log	2000-0880		
31. Right Front Ember Log	2000-0881		
32. Lava Rocks	57897		
33. Burner Assembly	3000-0446		
34. Manifold Tube Assembly	2000-0663		
35. Orifice Hood, Front - NG (#51)	3000-0449		
Orifice Hood, Front - LP (#60)	3000-0518		
36. Orifice Hood, Rear - NG (#42)	3000-0332		
Orifice Hood, Rear - LP (#54)	3000-0514		
37. Pilot, ODS w/TP-OP #84210 - NG	160-1929		
Pilot, ODS w/TP-OP #84210 - LP	160-1930		
38. Valve Bracket	140-9110		
39. Control Valve, NG / Honeywell 8421	1000-0235		
Control Valve, LP / Honeywell 8421	1000-0242		
40. Ignition Cable	2000-0101		
41. Pilot Bracket	2000-0851		
42. Pilot Tubing	3000-0448		
43. Firebox	130-1148		
44. Bottom	3000-0328		
45. Control Panel	140-9136		

For replacement parts, or for information about parts or service, contact your local Vermont Castings Authorized Dealer. For the name of the dealer nearest you, call or write:

The Majestic Products Company  
 1000 East Market Street  
 Huntington, IN 46750-2579  
 219-356-8000




Figure 36. RVUV40 Wiring Diagram