

RFSDV22/32/42 Part List

RFSDV22/32/42 Series (continued)

Ref.	Description	RFSDV22	RFSDV32	RFSDV42
1.	Log Set Complete	10000160	10000160	10000205
1a.	Log Ember Front	KR1	KR1	SR1
1b.	Log Front Left	KR2	KR2	SR2
1c.	Log Front Right	KR3	KR3	SR3
1d.	Log Rear	KR4	KR4	SR4
1e.	Log Top Left	KR5	KR5	SR5
1f.	Log Top Right	KR6	KR5	SR6
2.	Burner Lava Rock (Package)	57897	57897	57897
3a.	Burner with Tiles Nat.	57903	57903	10000866
3b.	Burner with Tiles Prop.	57904	57904	10000867
4.	Ceramic Tile (Single)	57803	57803	57803
5a.	Orifice Front Nat.	See Rating Plate for Orifice Size		
5b.	Orifice Front Prop.	See Rating Plate for Orifice Size		
6a.	Orifice Main Nat.	See Rating Plate for Orifice Size		
6b.	Orifice Main Prop.	See Rating Plate for Orifice Size		
7a.	Orifice Pilot SIT Nat.	54273	54273	54273
7b.	Orifice Pilot SIT Prop.	54272	54272	54272
8a.	Orifice Pilot PSE Nat.	10001822	10001822	10001822
8b.	Orifice Pilot PSE Prop.	10001823	10001823	10001823
9a.	Pilot Assembly SIT Nat.	10000674	10000674	10000674
9b.	Pilot Assembly SIT Prop.	10000675	10000675	10000675
10a.	Pilot Assembly PSE Nat.	10001741	10001741	10001741
10b.	Pilot Assembly PSE Prop.	10001742	10001742	10001742
11.	Pilot SIT	10001295	10001295	10001295
12.	Pilot w/ignitor and cable PSE	10001824	10001824	10001824
13.	Pilot Tubing w/fittings	53211	53211	53211
14.	Manifold Tubing w/fittings	57318	57318	57318
15.	Thermocouple SIT	53373	53373	53373
16.	Thermocouple PSE	10001825	10001825	10001825
17.	Thermopile	51827	51827	51827
18.	Electrode Ignitor w/cable SIT	10001297	10001297	10001297
19.	Ignitor Piezo SIT	52464	52464	50932
20.	Ignitor Piezo Honeywell	20000062	20000062	20000062
21a.	Valve SIT 820 Nat.	52677	52677	52677
21b.	Valve SIT 820 Prop.	52678	52678	52678
22.	Extension Knob Hi/Lo SIT (RN/RP)	10000165	10000165	55162
23.	Extension Knob On/Off SIT (RN/RP)	10000166	10000166	55163
24a.	Valve Honeywell Nat.	10001782	10001782	10001782
24b.	Valve Honeywell Prop.	10001759	10001759	10001759
25a.	Valve Eurosit 630 Nat.	53448	53448	53448
25b.	Valve Eurosit 630 Prop.	53446	53446	53446
26.	Fan with Bracket	54103	54103	54103
27.	Electrical Cord (6ft.)	51865	51865	51865
28.	Fan Temperature Sensor	51704	51704	51704
29.	Speed Control	51738	51738	51738
30.	Speed Control Knob	51882	51882	51882
31.	Glass with Gasket - Front	52035	52035	57581
32.	Glass with Gasket - Side	-	52032	-
33.	Gasket Glass	57316	57316	57317
34.	Glass Bay Window - Front	-	-	57477
35.	Glass Bay Window - Sides	-	-	57478
36a.	Frame Window - Left Side	-	52145	-

RFSDV22/32/42 Series (continued)

Ref.	Description	RFSDV22	RFSDV32	RFSDV42
36b.	Frame Window - Right Side	-	52860	-
37.	Frame Window - Front	57244	57244	57590
38.	Bay Window Assy. (w/glass)	-	-	57593
39.	Trim Frame Window (PB)	53477	52027	57583 ⁽¹⁾
40.	Trim Front Louvre (PB)	53455	-	-
41.	Top Louvre	57262	52019	-
42.	Front Louvre Assembly	57259	57908	57591
43.	Access Door Assembly (with handle)	53990	52030	57592
44.	Latch	52057	52057	52057
45.	Remote Switch	53606	53606	53606
46.	Remote Wire Harness with Terminals	10002582	10002582	100025820
47.	Clamp Frame Window	-	-	54174
48.	Ceramic Refractory Lining Kit (Not Shown)	-	-	10000846
49.	Ceramic Refractory Bay (ONLY Bay Set) (Not Shown)	-	-	10000847

www.woodmanspartsplus.com