

Vermont Castings UVS27 Stardance Part List

UVS27 Vent Free Gas Heater - Stardance Shell

Models 2795, 2796, 2797, 2798

Ref.	Description	UVS27
1.	UVS27R Firebox Assembly NG	0002797
	UVS27R Firebox Assembly LP	0002798
	UVS27M Firebox Assembly NG	0002795
	UVS27M Firebox Assembly LP	0002796
2.	Rear Shroud Assembly, UVS27	20000894
3.	End, Left - FS-VF25J/SDV30/SNV	Refer to Enamel Parts Chart Page 21
4.	End, Right - FS-VF25J/SDV30/SNV30	Refer to Enamel Parts Chart Page 21
5.	Top, UV30	Refer to Enamel Parts Chart Page 21
6.	VC Front, FS	Refer to Enamel Parts Chart Page 21
7.	Hinge, Control Door - FS/HM	1601670
8.	Door, Control - FS/HM	1301087
9.	Heatshield, Side - DH25	1409065
10.	Damper - ENC/NT II	1601488
11.	Pan Hd PH 1/4-20 x 3/8" - Bik	1200993
13.	Washer, FL 1/4- Pin 7/8 o.d.	1202470
14.	Washer, FL 1/4-Z .313i x .7420 .06+	1202474
16.	Wingscrew, 1/2-20 x 1/2 Pin	1201621
17.	Ring, Snap	1201987
18.	Leveling Bolt, Hex Hd 1/4-20 x 1-Z	1201745
19.	Screen, UVS27	20005009
20.	Grille, UV30	30000393
21.	Mesh, Grille 0 UV30	30000508
22.	Wiring/Thermostat Assembly - RVF	1601913
23.	Switch, ON/OFF - R/WDV	1601597
24.	Fan Kit (FK28) (Not Shown)	0002960

Shell Enamel Parts Chart - UVS27, Freestanding Shell				
Color	Top	Left End	Right End	Front
Classic	N/A	N/A	N/A	N/A
Red	N/A	N/A	N/A	N/A
Sand	N/A	N/A	N/A	N/A
Midnight	N/A	N/A	N/A	N/A
Green	N/A	N/A	N/A	N/A

UVS27 Parts Not Shown	
Log Set	20000892
Left Front Ember	30000135
Right Front Ember	30000134
Left Middle Log	20000989
Right Middle Log	20000988
Rear Log	30000129
Top Left Log	30000133
Top Right Log	20000990
Burner Assembly	20000889
Manifold Tube Assembly	20000663
Pilot Tubing	30000448
Igniter Cable	20000101
Lava Rock	57897
Front Burner Orifice NG	30000336
Front Burner Orifice LP	30000513
Rear Burner Orifice NG	30000334
Rear Burner Orifice LP	30000514
Pilot Assembly MN	20001356
Pilot Assembly RN	160-1929
Pilot Assembly MP	20001357
Pilot Assembly RP	160-1930
Valve MN	20001354
Valve RN	10000235
Valve MP	20001355
Valve RP	10000242