

Vistaflame VF 100 FS Freestanding Parts List

Reference Number	Description	Part Number
1	Exhaust Temperature Sensor 120°F (60°C)	EC-001
	Power Cord - 115V	EC-042
2	Auger Motor - 115V	EF-001
3	Convection Blower - 115V	EF-002
	Convection Blower Impeller	EF-004
	Convection Blower Insulator (Gasket)	EF-006
	Combustion Main Impeller	EF-008
	Combustion Blower Mounting Gasket	EF-011
	Combustion Blower Housing Gasket	EF-012
4	Fan Temperature Sensor 160°F (71°C)	EF-013
5	Ignition Temperature Sensor 120°F (49°C) Ceramic	EF-015
6	High Limit Temperature Sensor 200°F (93°C) Manual Reset	EF-016
7	Vacuum Switch - 115V	EF-017
	Silicone Hose	EF-018
	Aluminum Hose Barb	EF-019
8	Charcoal Burn Pot	EF-021
9	Auger	50-1346
12	Firebox Liner With Insulation	EF-047
	Slider Damper Rod With Knob	EF-050
	Heat Exchanger Rod With Knob	EF-051
	Tapped Corner Bracket	EC-053
	5/8" Door Gasket 7' (2.1 m)	50-088
	Window Channel Tape 60" (1.5 m)	EC-058
13	Insert Hopper Lid Knob & Stud Only	EF-059
14	Insert Ash Pan Latch	EF-060
15	Glass Set With Tape	EF-062
	Slider Damper Plate	EF-064

Woodman's Parts Plus
www.woodmanspartsplus.com

Reference Number	Description	Part Number
16	Auger Brass Bushings (Set of 2)	EF-065
	Firebox Liner Top Plate	EF-066
	¾" ID Auger Collar with Set Screw	EF-069
	Knob 1 Inch Round	EF-070
17	Freestanding Back Grill	EF-097
18	Freestanding Hopper Lid With Handle	EF-104
19	Fireplace Insert Ash Pan Drawer With Latch	EF-105
20	Ash Sill	EF-121
21	Insert Hopper Cover	EF-122
	Shoulder Bolt, Hardened Bush & Nut (Set of 2)	EF-124
	Firebox Ceramic Wool Insulation	EF-126
22	Steel Brick Lining	EF-129
23	Freestanding Right Cabinet Side	EF-133
	Ignitor Tube Only	EF-140
	Freestanding Hopper Lid Hinge	EF-141
25	Freestanding Hopper Side Rail (Left & Right)	EF-143
26	Insert Hopper Side Rail (Left & Right)	EF-145
	Pellet Stove Cleaning Brush	EF-156
27	Freestanding Ash Pan Latch	EF-178
	Insert Ash Pan Cover Magnet Set	EF-188
28	Firebox Cleaning Port Covers	EF-194A
29	Insert Hopper Lid With Knob, Stud, and Hinge	EF-202
	Pedestal & Ash Pan Gasket 10' (3 m)	EF-208
30	Insert Regular Panel with Black Trim	VF100-001
31	Insert Oversized Panel with Black Trim	VF100-002
32	Insert Pedestal	VF100-003
33	Door Cover - Gold (Post Jan 08)	VF100-012
33	Door Cover - Painted (Post Jan 08)	VF100-011

Woodman's Parts Plus
www.woodmanspartsplus.com

Reference Number	Description	Part Number
33	Door Complete (Post May 2010)	50-2529
34	Freestanding Pedestal	50-2530
35	Top - Freestanding	50-2532
36	Top - Insert	50-2533
37	Front Grill	50-2534
38	Bottom Grill	50-2535
	Owner's Manual	VF-50279
	Log Set	20-036
39	Control Panel Door	20-040
	Control Panel Touch Latch	50-323
40	Combustion Blower Exhaust Tube	50-327
41	Stainless Steel Burn Pot Liner - Standard	50-474
	Flush Handle for Hopper Lid (Freestanding)	50-523
	Convection Blower Mount	50-524
42	Stainless Steel Burn Pot Liner - High Ash	50-587
	Door Hinge Bracket	50-604
43	Fireplace Insert Cabinet Side Right	50-751
	Glass Extrusions (Set of 2)	50-767
44	Ash Drawer with Latch	50-2531
45	Exhaust Blower Assembly - 115V	50-901
46	Ignitor 300 Watt	50-1067
47	Circuit Board Control Panel	50-1475
48	Circuit Board Decal	50-1930
49	Circuit Board with Thermostat Switch - 115V	50-1929