

Fire Magic Grill A430S Parts List

Item	Description	A430s		A530s		A540s		A660s	
		Part No.	Qty.	Part No.	Qty.	Part No.	Qty.	Part No.	Qty.
1.	Stainless cooking grid (set of 2 or 3)	3542-S-2	1	23539-S-2	1	23543-S-3	1	23544-S-3	1
2.	Flavor grid (set of 2 or 3)	3063-S-2	1	3056-S-2	1	3064-S-3	1	3057-S-3	1
3.	Main burner	3042-50	2	3041-50	2	3042-50	3	3041-50	3
4.	Heatshield kit	24177-05	2	24177-05	2	24177-05	3	24177-05	3
5.	Silicone gasket	24177-06	2	24177-06	2	24177-06	3	24177-06	3
6.	Infrared burner *	3060	1	3050	1	3060	1	3050	1
7.	Oven lid	23729-53	1	23736-53	1	23733-53	1	23738-52	1
or	Oven lid w/ window *‡	N/A		N/A		N/A		24170-54	1
8.	Warming rack	3672S-M	1	3672S-M	1	3673S-M	1	3673S-M	1
9.	Back burner*	24130-11H	1	24130-11H	1	24170-11H	1	24170-11H	1
10.	Back burner cover*	24148-010	1	24148-010	1	24739-010	1	24739-010	1
11.	Rotisserie motor*	3600-02	1	3600-02	1	3600-02	1	3600-02	1
12.	Heavy-duty motor*	N/A		N/A		3600-05	1	3600-05	1
13.	Rotisserie rod*	3603-30	1	3603-30	1	3606-30	1	3606-30	1
14.	Heavy duty rod*	N/A		N/A		3606-40	1	3606-40	1
15.	Rotisserie knob*	24187-16	1	24187-16	1	24187-16	1	24187-16	1
16.	Meat holder (pair)*	3613	1	3613	1	3613	1	3613	1
17.	Counterbalance*	3620E	1	3620E	1	3620E	1	3620E	1
18.	Grid lifter	3519	1	3519	1	3519	1	3519	1
19.	Convertible regulator	PR-4	1	PR-4	1	PR-4	1	PR-4	1
20.	Valve manifold w/ back burner	24330-22	1	24330-22	1	24370-22	1	24370-22	1
or	Valve manifold w/o back burner	24330-24	1	24330-24	1	24370-24	1	24370-24	1
or	Valve manifold w/o side burner, w/ back burner	24130-22	1	24130-22	1	24170-22	1	24170-22	1
or	Valve manifold w/o side burner, w/o back burner	24130-28	1	24130-28	1	24170-28	1	24170-28	1
21.	Control panel w/ back burner	24330-45	1	24330-45	1	24370-45	1	24370-45	1
or	Control panel w/o back burner	24330-46	1	24330-46	1	24370-46	1	24370-46	1
or	Control panel w/o side burner, w/ back burner	24330-47	1	24330-47	1	24170-45	1	24170-45	1
or	Control panel w/o side burner, w/o back burner	24330-48	1	24330-48	1	24170-46	1	24170-46	1
22.	Small knob*	3016	1	3016	1	3016	1	3016	1
23.	Large knob	3015	2	3015	2	3015	3	3015	3
24.	Digital thermometer	24180-12H	1	24180-12H	1	24180-12H	1	24180-12H	1
25.	Meat probe	24187-14S	1	24187-14S	1	24187-14S	1	24187-14S	1
26.	Drip tray	3084	1	3084	1	3084	1	3084	1
27.	Drip tray liner (set of 4)	3557	1	3557	1	3557	1	3557	1

\* If equipped

‡ Not shown

Woodman's Parts Plus  
[www.woodmanspartsplus.com](http://www.woodmanspartsplus.com)

Item	Description	A430s		A530s		A540s		A660s	
		Part No.	Qty.	Part No.	Qty.	Part No.	Qty.	Part No.	Qty.
28.	Folding shelf	24316-15R/L	1	24326-15R/L	1	24316-15R/L	1	24326-15R/L	1
29.	Sideburner shelf (only)* ‡	24316-16	1	24326-16	1	24316-16	1	24326-16	1
30.	Paper towel holder assembly	25387-11	1	25387-11	1	25387-11	1	25387-11	1
31.	Tool holder assembly‡	25387-12	1	25387-12	1	25387-12	1	25387-12	1
32.	Door (left)	24330-19L	1	24330-19L	1	24370-19L	1	24370-19L	1
33.	Door (right)	24330-19R	1	24330-19R	1	24370-19R	1	24370-19R	1
34.	Door handle	3900-40	2	3900-40	2	3900-40	2	3900-40	2
35.	Caster kit (set of 4)	3400-7	1	3400-7	1	3400-7	1	3400-7	1
36.	Sideburner lid*	24336-31	1	24336-31	1	24336-31	1	24336-31	1
37.	Propane regulator / hose assy. or Natural Gas QD hose ‡	5110-07 5110-03	1 1	5110-07 5110-03	1 1	5110-07 5110-03	1 1	5110-07 5110-03	1 1
38.	Sideburner grid‡	3552	1	3552	1	3552	1	3552	1
39.	Sideburner assembly w/ shelf*	24336-33	1	24336-34	1	24336-33	1	24336-34	1
40.	Wire harness assembly‡	24177-28	1	24177-28	1	24177-28	1	24177-28	1
41.	Back burner electrode*‡	4199-52	1	4199-52	1	4199-52	1	4199-52	1
42.	Main burner electrode‡	3199-72	2	3199-72	2	3199-72	3	3199-72	3
43.	Natural gas orifice(s)‡	3001-42-2	1	3001-40-2	1	3001-44-3	1	3001-42-3	1
44.	Natural back burner gas orifice(s)‡	3001-52-1	1	3001-52-1	1	3001-48-1	1	3001-48-1	1
45.	Propane gas orifice(s)‡	3001-54-2	1	3001-53-2	1	3001-55-3	1	3001-54-3	1
46.	Propane back burner gas orifice(s)‡	3001-59-1	1	3001-59-1	1	3001-56-1	1	3001-56-1	1
47.	Fire Magic® cookbook‡	3595	1	3595	1	3595	1	3595	1
48.	Thermometer wire harness‡	24177-25	1	24177-25	1	24177-25	1	24177-25	1
49.	Power supply w/ connector	24177-12	1	24177-12	1	24177-12	1	24177-12	1
50.	12V / 10 watt halogen light bulb ‡	24187-15	2	24187-15	2	24187-15	2	24187-15	2
51.	Light lens ‡	24187-26	2	24187-26	2	24187-26	2	24187-26	2
52.	Lamp assembly ‡	24187-28	2	24187-28	2	24187-28	2	24187-28	2
53.	Light switch	24182-46	1	24182-46	1	24182-46	1	24182-46	1
54.	Propane tank tray (propane models only) ‡	25386-21	1	25386-21	1	25386-21	1	25386-21	1
55.	Magic View window (only) * ‡	N/A		N/A		N/A		24187-45	1

\* If equipped

‡ Not shown