

AOG American Outdoor Grill 24NBL

Item	Description	24"		30"		36"	
		Part No.	Qty.	Part No.	Qty.	Part No.	Qty.
1.	Stainless cooking grid (set of 2 or 3)	24-B-11	1	30-B-11	1	36-B-11	1
2.	Vaporizer panel	24-B-05	2	30-B-05	3	36-B-05	3
3.	Main burner	24-B-06	2	24-B-06	3	24-B-06	3
4.	Infrared burner*	IRB-18	1	IRB-18	1	IRB-18	1
5.	Backburner*	24-B-17T	1	24-B-17T	1	36-B-17T	1
6.	Thermometer	24-B-10	1	24-B-10	1	24-B-10	1
7.	Oven lid	24-B-25	1	30-B-25	1	36-B-25	1
8.	Warming rack	24-B-02	1	30-B-02	1	36-B-02	1
9.	Drip tray with match holder	3083	1	3083	1	3083	1
10.	Control panel w/ backburner	24-B-26L	1	30-B-26L	1	36-B-26L	1
	or Control panel w/o backburner ‡	24-B-27L	1	30-B-27L	1	36-B-27L	1
11.	Ignitor module w/ backburner	3199-44	1	3199-44	1	3199-44	1
	or Ignitor module w/o backburner ‡	24-B-49	1	3199-44	1	3199-44	1
12.	Valve manifold w/ backburner	24-B-08	1	30-B-08	1	36-B-08	1
	or Valve manifold w/o backburner ‡	24-B-34	1	30-B-34	1	36-B-34	1
13.	Main burner electrode / ignitor assy	24-B-04	2	24-B-04	3	24-B-04	3
14.	Large knob	3015	2	3015	3	3015	3
15.	Small knob*	3016	1	3016	1	3016	1
16.	Convertible regulator ‡	PR-4	1	PR-4	1	PR-4	1
17.	Drip tray heat shield	24-B-44	1	24-B-44	1	24-B-44	1
18.	12V / 10 watt halogen light bulb ‡	24187-15	2	24187-15	2	24187-15	2
19.	Light lens ‡	24187-26	2	24187-26	2	24187-26	2
20.	Lamp assembly ‡	24187-28	2	24187-28	2	24187-28	2
21.	Light switch	24-B-45	1	24-B-45	1	24-B-45	1
22.	Ignitor switch	24-B-46	1	24-B-46	1	24-B-46	1
23.	Power supply w/ connector	24-B-47	1	24-B-47	1	24-B-47	1
24.	Wire harness assembly ‡	24-B-48	1	24-B-48	1	24-B-48	1
25.	Wire harness extension	24182-53	1	24182-53	1	24182-53	1
26.	Flex connector w/ fittings ‡	3035	1	3035	1	3035	1

* If equipped

‡ Not shown