

AOG American Outdoor Grill 30NBT Parts List

Item	Description	24"		30"		36"	
		Part No.	Qty.	Part No.	Qty.	Part No.	Qty.
1.	Stainless cooking grid (set of 2 or 3)	24-B-11	1	30-B-11	1	36-B-11	1
2.	Vaporizer panel	24-B-05	2	30-B-05	3	36-B-05	3
3.	Main burner	24-B-06	2	24-B-06	3	24-B-06	3
4.	Backburner*	24-B-17T	1	24-B-17T	1	36-B-17T	1
5.	Thermometer	24-B-10	1	24-B-10	1	24-B-10	1
6.	Oven lid	24-B-25	1	30-B-25	1	36-B-25	1
7.	Warming rack	24-B-02	1	30-B-02	1	36-B-02	1
8.	Drip tray with match holder	3083	1	3083	1	3083	1
9.	Control panel w/ backburner or Control panel w/o backburner ‡	24-B-26T 24-B-27T	1 1	30-B-26T 30-B-27T	1 1	36-B-26T 36-B-27T	1 1
10.	Valve manifold w/ backburner or Valve manifold w/o backburner ‡	24-B-08T 24-B-34T	1 1	30-B-08T 30-B-34T	1 1	36-B-08T 36-B-34T	1 1
11.	Main burner ignitor assy only	24-B-04T	2	24-B-04T	3	24-B-04T	3
12.	Main burner valve w/ ignitor assy	24-B-51T	2	24-B-51T	3	24-B-51T	3
13.	Backburner valve w/ ignitor assy*	24-B-50T	1	24-B-50T	1	24-B-50T	1
14.	Large knob	24-B-37T	2	24-B-37T	3	24-B-37T	3
15.	Small knob*	24-B-38T	1	24-B-38T	1	24-B-38T	1
16.	Convertible regulator ‡	PR-4	1	PR-4	1	PR-4	1
17.	Drip tray heat shield	24-B-44	1	24-B-44	1	24-B-44	1
18.	Flex connector w/ fittings ‡	3035	1	3035	1	3035	1

\* If equipped

‡ Not shown