

Atlanta Sunny Jim Model 40/75/100 Parts List

| <b>Ref#</b> | <b>Description</b>  | <b>Model 40</b>  | <b>Model 75</b>  | <b>Model 100</b> |
|-------------|---------------------|------------------|------------------|------------------|
| 1           | Shaker              | 9                | 9                | 9                |
| 2           | Grate Rest          | 453              | 453              | 2808             |
| 3           | Front Half Collar   | 1443             | 1443             | 1443             |
| 4           | Back Half Collar    | 1444             | 1444             | 1444             |
| 5           | Draft Door          | 1643             | 1643             | 1643             |
| 6           | Main Top            | 2535             | 2535             | 2800             |
| 7           | Grate Frame         | 2536             | 2536             | 2806             |
| 8           | Side Liner          | 2537             | 2537             | 2802             |
| 9           | Back Liner          | 2538             | 2538             | 2803             |
| 10          | Front Liner         | 2539             | 2539             | 2804             |
| 11          | Collar Strip        | 2540             | 2540             | 2540             |
| 12          | Slide Grate         | 2541             | 2541             | 2807             |
| 13          | Smoke Guard         | 2542             | 2542             | 2814             |
| 14          | Base Door Frame     | 2543             | 2543             | 2809             |
| 15          | Base Door           | 2544             | 2549             | 2810             |
| 16          | Fire Door Frame     | 2545             | 2545             | 2815             |
| 17          | Fire Door           | 2546             | 2546             | 2812             |
| 18          | Base Door hinge     | 2547             | 2547             | 2547             |
| 19          | Grate Frame Support | 2548             | 2548             | 2805             |
| 20          | Smoke Guard Hinge   | 2550             | 2550             | 2550             |
| 21          | Register            | 4                | 4                | 4                |
| 22          | Drum Assembly       | CS-5027          | CS-5029          | CS-2825          |
| 23          | Base Assembly       | CS-5028 / 400764 | CS-5028 / 400764 | S-2823 / 400763  |
| 24          | Ash pan Assembly    | CS-5026 / 400762 | CS-5026 / 400762 | CS-2824 / 400763 |
| 25          | Top Cleat           | C-5017           | C-5017           | C-5017           |
| 26          | Base Door Handle    | 6.022-102        | 6.022-102        | 6.022-102        |
| 27          | Base Door Latch     | 6.024-103        | 6.024-103        | 6.024-103        |
| 28          | Wire Lift Handle    | 6.022-100        | 6.022-100        | 6.022-100        |
| 29          | Fire Brick Liner    | 154-410          | 6.111-101        | 6.111-103        |
| 30          | Spring Knob         | 6.022-300        | 6.022-300        | 6.022-300        |
| 31          | Hinge Pin           | 6.023-200        | 6.023-200        | 6.023-200        |