

Enviro EF5 Evolution Pellet Stove

EF-037	POWER UP TIMER	20-038	EF5 CAST TOP
EF-043	START-UP SWITCH	20-045	EF 5 FIREBOX BRICK LINER
EF5-101	S.S. SIDE PANELS (2) AND HOPPER LID	20-054	EF5 S.S. BURN POT LINER
EF5-103	EVOLUTION HEARTH PAD	20-073	EF 5 UPGRADE KIT
EF5-104	OUTSIDE COMBUSTION BLOWER HOUSING	20-074	EF 5 DIAL-A-FIRE
EF5-105	200 HIGH LIMIT TEMP SENSOR MR	20-094	EF5 TOP GLASS RETAINER
EF5-106	FAN CONTROLLER	50-084	EF5 THERMOSTAT INTERFACE ONLY
EF5-107	GREEN LIGHT	50-088	EF5 DOOR GASKET (60 INCHES)
EF5-109	120° F EXHAUST TEMP SENSOR	50-096	EF5 EXTERIOR EXHAUST ADAPTER
EF5-110	120° F IGNITION TEMP SENSOR	50-097	EF5 NICKEL LOUVER SET
EF5-112	AUGER TIMER CONTROL	50-162	EF5 ASH LIP LOUVER NICKEL
EF5-113	POWER UP TIMER		
EF5-114	COMBUSTION BLOWER		
EF5-115	VACUUM SWITCH		
EF5-116	AUGER MOTOR		
EF5-118	AUGER		
EF5-119	CONVECTION BLOWER		
EF5-120	CONVECTION BLOWER MOUNT		
EF5-121	CONTROL PANEL DOOR		
EF5-122	CONTROL PANEL		
EF5-123	CONTROL PANEL DECAL		
EF5-124	EF5 FIREBOX LINER		
EF5-128	BURN POT		
EF5-129	ASH PAN		
EF5-131	ASH PAN COVER		
EF5-134	DOOR HANDLE		
EF5-136	PAINTED DOOR ONLY		
EF5-137	SLIDER DAMPER PLATE		
EF5-138	HEAT EXCHANGER ROD		
EF5-139	BACK GRILL		
EF5-140	HOPPER LID PAINTED		
EF5-149	IEC POWER CORD		
20-018	EF5 LEVELING LEGS		
20-019	EF5 OWNERS MANUAL		
20-020	EF5 HARDENED BUSHING		
20-021	EF5 WIRING HARNESS		
20-022	EF5 IGNITER 120 V		
20-023	EF5 GLASS (356 X 356 MM)		
20-024	EF5 AUGER SHAFT		
20-025	EF5 LIGHTING INSTRUCTIONS		
20-026	EF5 THERMOSTAT CONTROLLER		
20-029	EF5 S.S. CAB SIDE LEFT		
20-030	EF5 S.S. CAB SIDE RIGHT		
20-031	EF5 PAINTED CAB SIDE LEFT		
20-032	EF5 PAINTED CAB SIDE RIGHT		