

American Hearth Mantis Fireplace Part List

FIREPLACE MANTIS PARTS LIST

⚠ WARNING

Use only manufacturer's replacement parts. Use of any other parts could cause injury or death.

| INDEX NO. | PART NO. | DESCRIPTION | INDEX NO. | PART NO. | DESCRIPTION |
|-----------|----------|---|-----------|----------|--|
| 1 | 25207 | PANEL - TOP | 38 | 26088 | SUMP ASSEMBLY (INCLUDES #62 & 64) |
| 2 | 21595 | CONDENSATE TRAY | 39 | 26089 | FLEX PIPE ASSEMBLY (REQUIRES 2 #65) |
| 3 | 25223 | LOUVER - TOP | 40 | 29721 | HEAT EXCHANGER ASSEMBLY (INCLUDES #39, 62, & 65) |
| 4 | 30630 | REAR BURNER TRAY | 41 | 25204 | PANEL - BACK |
| 5 | R9987 | FLEX LINE | 42 | R10796 | ORIFICE HOLDER - REAR |
| 6 | 30633 | FRONT BURNER TRAY ASSEMBLY | 43 | R10182 | WIRE HARNESS - 120V |
| 7 | 25205 | PANEL - LEFT SIDE | 44 | R10190 | WIRE HARNESS - 12V SMALL |
| 8 | 21605 | INLET AIR DUCT COVER | 45 | R10183 | WIRE HARNESS - 12V LARGE |
| 9 | 22780 | INLET AIR DUCT ASSEMBLY | 46 | 22773 | THERMISTOR ASSEMBLY |
| 10 | R10491 | INLET AIR DUCT GASKET | 47 | R11043 | WIRE HARNESS - CIRCUIT BOARD |
| 11 | R8825 | SOLENOID | 48 | R10759 | RIBBON CABLE |
| 12 | R10072 | GAS SHUT OFF VALVE | 49 | 24831 | REAR HEAT SHIELD ASSEMBLY |
| 13 | R8812 | VALVE - NAT | 50 | 25325 | CONDENSATE PUMP COVER |
| 13 | R8869 | VALVE - LPG | 51 | R11455 | REAR LOG |
| 14 | 26071 | GLASS ASSEMBLY | 52 | RR1456 | LEFT LOG |
| 15 | 27004 | CIRCULATING BLOWER ASSEMBLY | 53 | R10380 | RIGHT LOG |
| 16 | R10338 | PRESSURE SWITCH | 54 | R11457 | MIDDLE LOG |
| 17 | 25227 | ELECTRICAL PARTS PLATE | 55 | R10378 | FRONT LEFT LOG |
| 18 | R10775 | CONTROL BOX (INCLUDES #27 & 48) | 56 | R10377 | FRONT RIGHT LOG |
| 19 | R10043 | TRANSFORMER 12-24V | 57 | R10383 | LEFT TOP LOG |
| 20 | R8881 | CAPACITOR 3uF | 58 | R10382 | RIGHT TOP LOG |
| 21 | R8880 | CAPACITOR 4uF | 59 | 25216 | BRACKET, STANDOFF (2 REQUIRED) |
| 22 | R8804 | TRANSFORMER - 24V | 60 | R2522 | MAIN POWER SWITCH |
| 23 | 26075 | PUMP ASSEMBLY (INCLUDES #50 & 64) | 61 | R10610 | WIRE HARNESS, MAIN POWER SWITCH |
| 24 | 25226 | CIRCUIT BOARD PLATE | 62 | R8795 | GASKET - SUMP |
| 25 | R8809 | DOUBLE ROCKER SWITCH | 63 | 26119 | HEADER COVER - OUTLET |
| 26 | R8840 | WIRE HARNESS ASSEMBLY WITH ECONOMY SWITCH | 64 | R10966 | TUBING (SUMP TO PUMP) |
| 27 | R8904 | CIRCUIT BOARD | 65 | R10337 | GASKET, END PLATE (2 REQUIRED) |
| 28 | 30547 | FRONT BURNER ASSEMBLY | N/S | 26117 | AIR DUCT CHANNEL COVER PLATE - NAT ONLY |
| 29 | 30546 | BACK BURNER ASSEMBLY | N/S | FRBTC | THERMOSTAT |
| 30 | R11012 | ORIFICE HOLDER - FRONT | N/S | R10093 | ORIFICE #47 - NAT |
| 31 | 22865 | HOT SURFACE IGNITOR (2 REQUIRED) | N/S | R10094 | ORIFICE #49 - NAT |
| 32 | R10967 | FLAME SENSOR (2 REQUIRED) | N/S | R10095 | ORIFICE #1.2MM - LP |
| 33 | 25210 | AIR DUCT CHANNEL | N/S | R10096 | ORIFICE #55 - LP |
| 34 | 25214 | PANEL - RIGHT SIDE | N/S | R10299 | SWITCH, BIMETALIC |
| 35 | 25222 | DOOR BRACKET (2 REQUIRED) | N/S | R10705 | FILTER, FRONT PANEL |
| 36 | R4053 | DOOR CLAMP (2 REQUIRED) | N/S | R10706 | FILTER ROD, FRONT PANEL |
| 37 | 25225 | LATCH BRACKET (2 REQUIRED) | | | |