

Empire Keystone Deluxe Part List

BVD34 & BVD36 PARTS LIST

| INDEX NO. | PART NUMBER | | | | DESCRIPTION |
|-----------|-------------|--------|--------|--------|--|
| | BVD34L | BVD34F | BVD36L | BVD36F | |
| 1 | 19506 | 19506 | 19507 | 19507 | TOP SHIELD |
| 2 | 17301 | 17301 | 17301 | 17301 | TOP STANDOFF (2 REQUIRED) |
| 3 | 10554 | 10554 | 10554 | 10554 | NAILING FLANGE (4 REQUIRED) |
| 4 | M163 | M163 | M178 | M178 | FLUE OUTLET GASKET |
| 5 | 19387 | 19387 | 19422 | 19422 | FLUE OUTLET ASSEMBLY |
| 6 | 19398 | 19398 | 19398 | 19398 | DOWNDRAFT BAFFLE |
| 7 | 19402 | 19402 | 19434 | 19434 | DRAFT BAFFLE |
| 8 | R7052 | R7052 | R7052 | R7052 | SCREEN ROD |
| 9 | R8137 | R8137 | R8148 | R8148 | SCREEN |
| 10 | 17127 | N/A | 18807 | N/A | UPPER LOUVER ASSEMBLY |
| 11 | 17128 | N/A | 18808 | N/A | LOWER LOUVER ASSEMBLY |
| 12 | 17162 | 17162 | 17162 | 17162 | JUNCTION BOX ASSEMBLY (DIRECT IGNITION & LOUVERED MODELS ONLY) |
| 12a | 17163 | 17163 | 17163 | 17163 | JUNCTION BOX COVER PLATE |
| 13 | R3492 | R3492 | R3492 | R3492 | RECEPTACLE (DIRECT IGNITION & LOUVERED MODELS ONLY) |
| 14 | 19435 | 19435 | 19436 | 19436 | VALVE ACCESS DOOR |
| 15 | 17235 | 17235 | 17235 | 17235 | LOG LOCATOR BRACKET |
| 16 | R7580 | R7580 | R8020 | R8020 | BURNER TUBE |
| 17 | R5676 | R5676 | R5676 | R5676 | AIR SHUTTER |
| 18 | P252 | P252 | P286 | P286 | ORIFICE (NAT) |
| 19 | R7572 | R7572 | R7572 | R7572 | JAMB NUT |
| 20 | P212 | P212 | P212 | P212 | ORIFICE HOLDER |
| 21a | 19384 | 19384 | 19420 | 19420 | TUBING ASSEMBLY |
| 21b | 20208 | 20208 | 20209 | 20209 | TUBING ASSEMBLY |
| 22 | R2423 | R2423 | R2423 | R2423 | MALE ADAPTOR |
| 23 | R7590 | R7590 | R7590 | R7590 | SPARK IGNITOR (DIRECT IGNITION) |
| 24 | 17315 | 17315 | 17315 | 17315 | SPARK IGNITOR MOUNTING PLATE (DIRECT IGNITION) |
| 25 | R8132 | R8132 | R8132 | R8132 | PILOT (MILLIVOLT) |
| 25a | R5710 | R5710 | R5710 | R5710 | THERMOPILE |
| 26 | R7617 | R7617 | R7617 | R7617 | PILOT GASKET |
| 27 | 19382 | 19382 | 19418 | 19418 | BURNER BASE ASSEMBLY |
| 28a | 19381 | 19381 | 19381 | 19381 | VALVE BRACKET (MILLIVOLT) |
| 28b | 19403 | 19403 | 19403 | 19403 | VALVE BRACKET (DIRECT IGNITION) |
| 29a | R8380 | R8380 | R8380 | R8380 | VALVE, GAS (MILLIVOLT) |
| 29b | R7568 | R7568 | R7568 | R7568 | VALVE, DIRECT IGNITION (120V) |
| 30 | R2708 | R2708 | R2708 | R2708 | PIEZO IGNITOR (MILLIVOLT) |
| 31 | R7613 | R7613 | R7613 | R7613 | IGNITOR WIRE (SPARK PLUG WIRE) (DIRECT IGNITION) |
| 32 | R8143 | R8143 | R8143 | R8143 | CONTROL MODULE, ELECTRONIC (DIRECT IGNITION) |
| 33 | R8144 | R8144 | R8144 | R8144 | WIRE ASSEMBLY (DIRECT IGNITION) |
| 34 | R7615 | R7615 | R7615 | R7615 | CORD SET (DIRECT IGNITION) |
| 35a | R8133 | R8133 | R8133 | R8133 | WIRE ASSEMBLY, LIMIT SWITCH (MILLIVOLT) |
| 35b | R8147 | R8147 | R8147 | R8147 | WIRE ASSEMBLY, LIMIT SWITCH (DIRECT IGNITION) |
| 36 | R8145 | R8145 | R8145 | R8145 | WIRE ASSEMBLY, WALL SWITCH (ON/OFF) |
| 37 | R7587 | R7587 | R7556 | R7556 | REAR LOG |
| 38 | R7586 | R7586 | R7555 | R7555 | MIDDLE LOG |
| 39 | R7585 | R7585 | R7553 | R7553 | FRONT LEFT LOG |
| 40 | R-7588 | R7588 | R7557 | R7557 | Y BRANCH |
| 41 | R7554 | R7554 | R7554 | R7554 | FRONT RIGHT LOG |
| 42 | R7591 | R7591 | R7591 | R7591 | FLEX LINE/SHUTOFF VALVE |
| 43 | R8593 | R8593 | R8375 | R8375 | SWITCH, LIMIT |