

Waterford Emerald Insert B Vent Parts List

	Part #	Description
2)	936-243	Gasket - 7/8" w/adhesive
49)	*	Hose Clamp 3-1/16" - 4"
60)	270-013	Front Glass Frame
61)	940-080/P	Front Glass
62)	41212	Gasket - 1/4" x 1" Flat w/adhesive
65)	270-014	Side Glass Frame
66)	940-081/P	Side Glass
67)	*	Right Mounting Bracket
68)	*	Stove Front
69)	*	Left Mounting Bracket
70)	*	Screw - #8 x 1/2" Hex Slotted
71)	270-565	Relief Door Assy
77)	270-520/P	Fan Assembly
79)	270-019	Rear Panel
	910-157/P	Fan Blower
99)	W843310	Terminal Strip
100)	*	Base Plate
101)	591-187	Firebox Baffle
102)	*	Firebox
103)	*	Heat Exchanger Assy
104)	*	Flex Pipe
105)	*	Transition Box Assy
106)	*	Gasket - Transition Box
107)	910-233	Fan Auto ON/OFF Thermodisc
108)	*	Thermodisc Bracket
109)	*	Stove Top
110)	*	Top Face
111)	*	Insulation of Vent
113)	*	Adaptor Holding Bracket-Right
114)	*	Insulation Hold Down Bracket
115)	320-518	Flue Adaptor Assembly
116)	*	Adaptor Holding Bracket-Left
117)	*	Adaptor Stop
	908-429	Manual
	261-969	Conversion Kit - NG to LP

*Not available as a replacement part.

	Part #	Description
1)	942-031**	Decorative Door Grill Front
3)	*	Screw - 1/4 x 1/2" Flat Head Phillip Zinc Plate
4)	942-021**	Front Door
5)	W310201**	Louver Grill
6)	W310230	Guide Pin
7)	*	Magnet Mounting Plate
8)	904-258	Door Magnet
10)	44351	2" Black Butt Hinge
12)	*	Air Plate
16)	*	Door Mounting Bracket
18)	942-011**	Cast Front
	31701**	Shroud set - Regular
20)	W313281**	Top Surround-Regular
21)	W313261**	Left Surround-Regular
22)	W313271**	Right Surround-Regular
26)	W31077K	Knob for Rheostat (120 V)
27)	910-241	Burner ON/OFF Switch
28)	910-178	Grommet for power cord
29)	270-056	Control Plate
30)	W310770	Fan Speed Control Rheostat (120 V)
32)	904-656	Blanking Plug for Strain Relief
33)	910-822	Power Cord (120 V)
	910-721	High Temp. Wire Harness - Main Switch
	910-687	High Temp. Wire Harness - Motor Connect
	910-718	High Temp. Wire Harness - Fan & Valve
35)	270-055	Switch Box
36)	*	Washer 1/4 Flat
37)	*	Screw 1/4-20 x 1-1/4" Pan Head Phillip
40)	W310191**	Top Grill
41)	W310321	Lower Hob Heat Shield
42)	W310322	Upper Hob Heat Shield
43)	W310241**	Hob
44)	270-057	Shroud Bracket
	31711**	Shroud Set - Oversize
150)	W317261**	Left Surround-Oversize
151)	W317271**	Right Surround-Oversize
153)	W317281**	Top Surround-Oversize
154)	*	Screw 1/4 - 20 x 3/8"

	Part #	Description
52)	910-190	Piezo Ignitor & Nut
56)	908-672	Control Panel Decal
57)	490-061	Control Panel
	270-574/P	S.I.T. Valve Assy - NG
	270-576/P	S.I.T. Valve Assy - LP
58)	910-378	Valve S.I.T. - NG/LP
	936-170	Orifice Gasket
66)	910-038	Pilot Assy - S.I.T. - 3 Flame NG
	910-039	Pilot Assy - S.I.T. - 3 Flame LP
67)	*	Pilot Holder
68)	W840470	Pilot Assembly Gasket
78)	651-580	Burner Assy - NG/LP
80)	260-565	Adjustment Gear Assy
81)	904-565	Hex Key 3/16" AF
82)	630-009	Burner Tray/Air Passage Gasket
83)	630-008	Burner Tray/Firebox Gasket
84)	*	Front Support
87)	560-935	Log Set
88)	902-182	Log - Top
90)	*	Valve Mounting Bracket
92)	270-036	Valve Gasket
93)	*	Valve Support
94)	904-658	Gas Inlet Flex Line
	904-688	Orifice #32 - NG
	904-641	Orifice #50 - LP
	904-593	Orifice #40 (Conversion to Lower BTU Kit) NG
	904-390	Orifice #52 (Conversion to Lower BTU Kit) LP

*Not available as a replacement part.