

1500HT/1500HTL

MODEL: 1500HT/1500HTL		
DESC. FREESTANDING, TOP VENT, 6" FLUE		
MODEL YRS: 1989-1997		
PART NBR	DESCRIPTION	REMARKS
	DOOR PARTS	
1.G6000	DOOR ASSEMBLY, GOLD	
1.G6000-1	DOOR FRAME W/GASKET	
1.86-128	DOOR GASKET KIT, 3/4 INCH ROPE	INCLUDES ADHESIVE
1.10580	GASKET, GLASS CHANNEL (PER FOOT)	REQUIRES 5'
1.G2000-7	GLASS, ARCHED (9 1/2 X 15 3/4)	●
1.10300	HANDLE ASSEMBLY	GOLD DOOR
1.85-11	HANDLE, COIL SPRING	*SN > 5379
1.11529	HINGE, PIN 10 L 18	
1.00340	NUT, TOP LOCK 3/8-16	TORQUE PLATE NUT
1.10362	TORQUE PLATE	LATCH
	MODULE ASSEMBLY PARTS	
1.12095	MODULE ASSEMBLY	
1.00907	MODULE CONTROL HANDLE	
	COMPONENT PARTS	
1.01100	ASH DRAWER	
1.11709	ASH DUMP ASSEMBLY	*SN < 6001
1.11811	ASH DUMP INSULATION	*SN < 6001
1.00715	BOLT, LEG	REQUIRES 1 PER LEG
1.01098	GASKET, ASH DRAWER	REQUIRES 2'
1.01135	KNOB, ASH DRAWER	
1.00950	LEG, CAST IRON	
1.13009	TRIM, TOP LOUVER	
	FIREBOX PARTS (SEE BRICK DIAGRAM FOR BRICK PART NUMBERS)	
1.12020	FRONT AIR TUBE ASSEMBLY	
1.01115	GRATE, CAST IRON	*SN > 6001
1.12030	REAR TUBE ASSEMBLY	
	MISCELLANEOUS PARTS	
1.1054	CERAWOOL PAD, FOR MARBLE	REQUIRES 1
1.1051	CERAWOOL STRIPS, FOR MARBLE	REQUIRES 4
1.14440	DIAL-A-TEMP (RHEOSTAT)	
1.12086	INSTRUCTION MANUAL	
1.76-117B	NAMEPLATE	

*SN Stove serial number range, parts are compatible with:
">" = higher than # indicated, "<" = less than # indicated, "-" numbers within ra
● Glass insulation is not included w/glass replacement