

Part Number	Description
Burner Assemblies	
HA-20-00022	Main valve assembly NG (1994)
HA-20-00025	Burner w/Support (1994)
HA-20-00023	Main valve assembly LP (1994)
HA-20-00061	Main valve assembly NG (1995, 1996)
HA-20-00062	Main valve assembly LP (1995, ,1996)
AA-11-00250	Kit, burner valve conversion, NG - DXV-I to DXV-II
AA-11-00251	Kit, burner valve conversion, LP - DXV-I to DXV-II
05-02-00238	Main gas valve NG (1994 - 1996)
05-02-00239	Main gas valve LP (1994 - 1996)
HA-20-00057	Burner tube weldment (1995, 1996)
HA-20-00058	Aibox (1995, 1996)
05-04-00020	Pilot Hood & Ignitor - Robertshaw control (1994) ***SEE REMARKS***
05-04-00022	Pilot Hood & Ignitor - Robertshaw control (1995) ***SEE REMARKS***
05-04-00024	Pilot assembly with T-pile and Ignitor - NG & LP - DXV III (1996)
05-04-00025	Pilot assembly with T-pile and Ignitor - LP - DXV III (1996)
HA-19-00140	Pilot Tube DXV II - DXV III (1995, 1996)
05-07-00061	Thermopile (1995)
05-07-00065	Thermopile ITT (1996) Fat Style T-Pile
05-02-00236	Hi/Low regulator LP (1994 - 1996)
05-02-00237	Hi/Low regulator NG (1994 - 1996)
65-03-00021	Pilot orifice Nat. Gas (RS .026) (1994, 1995)
65-03-00018	Pilot orifice L.P. Gas (RS .018) (1994, 1995)
65-06-00949	Pilot orifice NG (ITT .024) (1996)
65-06-00950	Pilot orifice LP (ITT .013) (1996)
65-14-00031	Main orifice NG #31 (1994)
65-14-00048	Main orifice LP #48 (1994)
65-14-00030	Main orifice Nat. Gas # 30 (1995, 1996)
65-14-00049	Main orifice L.P. Gas # 49 (1995, 1996)
10-10-00136	Micro switch for blow-off relief cap (1994, 1995)
65-02-00054	Friction O-ring for blow-off relief cap (1994, 1995)
65-06-00348	Explosion Flange
65-06-00377	Explosion Cap
05-01-00154	High limit switch (1994 - 1996)

Blowers	
15-02-00044	Blower w/motor (1994) (Squirrel cage 12" long)
15-02-00047	Blower w/motor (1995, 1996) (Squirrel cage 7' long x 2" diameter)
The last (500) units built of the DXV-III used one of the standard blow	
15-02-00042	Blower w/motor (1996)
10-01-00003	Rheostat (1994 - 1996)
05-01-00157	Thermo-disc (1994 - 1996)
05-01-00191	Magnetic Thermo-disc bracket assembly

Part Number	Description
Logs	
35-01-00169	Log set with coals (1994)
35-01-00202	Split log set with coals (1995)
35-01-00214	Split log set (24") (1996)
35-01-00216	Bay floor brick
35-01-00186	Firebrick kit (1994)
45-01-00201	Firebrick kit (1994 - 1996)
35-01-00217	Firebrick floor kit (1995 - 1996)
35-01-00423	Firebrick kit (1994 - 1996)
HA-19-00138	Firebrick side clip (ea) (1995, 1996)
35-01-00187	Bag of coals
35-01-00239	Glowing Inswool
AA-11-00317	Log upgrade kit DXV-II & DXV-III to DXV-42
Kits upgrade units from the 35-01-00214 log to the 35-01-00226 Split 24" log set. Kit includes andiro current 35-01-241 Random log set. How	

Venting	
AA-11-00194	5' of Dual 4" Intake Air Pipe and Insulated Exhaust Pipe
AA-11-00195	25' of Dual 4" Intake Air Pipe and Insulated Exhaust Pipe
AA-11-00236	Vertical Vent Boot
45-01-00113	Horizontal Cap for Dual 4" Intake and Exhaust

Miscellaneous	
65-06-00367	Magnet (1)
HA-19-00073	Magnet Bracket (1)
65-06-00372	Door Hinge (1 pair)
HA-19-00065	Door Hinge mounting bracket (1)
65-02-00055	Tadpole Door Gasket (Sold by the foot) (1994 - 1996)
65-06-00336	Glass door pane Flat (1994 - 1996)
65-06-00434	Glass - bay
65-02-00068	Bay Glass Flat Gasket - installs between metal door frame and glass
HA-20-00007	Door frame assembly (1994)
HA-20-00049	Door frame assembly (1995 - 1996)
AA-11-00228	Firescreen & frame rect. (1994)
AA-11-00229	Firescreen & frame arch (1994)
HA-20-00103	Bay door frame assembly
05-01-00198	Wall Thermostat
65-06-00149	Piezo
65-06-00425	Springs for Catch Assembly
65-02-00065	ExplosionDoorGasket-Top (1995, 1996)
65-02-00066	ExplosionDoorFrameGasket-Bottom (1995, 1996)
HA-19-00241	DXVI, II Vinyl Shield for CoLinear Vent Cap
65-06-01049	Black Touch up paint
05-02-00251	Brass On/Off Valve with 90 Degree Elbow/Union