

Country Hearth 2200I Insert Part List

Key	Part No.	Description	Qty.
18	88158	Fiber Board, Front	1
19	88159	Fiber Board, Rear	1
20	88160	Fiber Blanket	1
21	80598	Blower Assembly	1
22	891991	Surround, Top	1
23		Surround, Left Side	1
24		Surround, Right Side	1
25	83913	Spring	2
26	891992	Trim-R, Surround	1
27		Trim-L, Surround	1
28		Trim-Top_L, Surround	1
29		Trim-Top_R, Surround	1
30	891993	Key, Straight	1
31		Key, Blank Straight	1
32		Key, Blank Corner (Can Use 89420)	2
33		Key, Corner (Can Use 89419)	2

Key	Part No.	Description	Qty.
1	69660	Complete Door Assembly	1
2	88057	5/8" Rope Gasket	6 ft.
3	891813	Door Glass	1
4	88087	Glass Gasket	4 ft.
5	25465	Glass Retainers	2
6	83202	Machine Screw - 10-24 x 3/8 Ph Hd.	4
7	83278	Washer - 7/32 ID X 1/2 OD	4
8	891373	Hinge Pad	2
9	25080	Door Latch (Uses 83508 - 5/16-18 x 3/4 bolt)	1
10	891989	Firebrick (4.5 x 9) (Can Use 89066)	9
11		Firebrick (3.33 x 9)	6
12		Firebrick (2.25 x 9) (Can Use 891414)	1
13		Firebrick (1.25 x 2.25)	1
14		Firebrick (3.38 x 9)	2
15	86669	Tube #1, Secondary Comb.	2
16	86670	Tube #2, Secondary Comb.	1
17	891990	Retainer, Tube	3