


H300 MAIN ASSEMBLY


	Part #	Description
1	220-160	Grill Cast - Top
2	220-371	Stove Top - Charcoal Grey
	220-374	Stove Top - Ivory
	220-375	Stove Top - Timberline Brown
3	220-522	Firebox Assembly - Top
4	220-514	Baffle Assembly
5	220-028	Back Shield
6	220-431	45 Degree Elbow - Charcoal Grey
7	220-140	Main Cast - Back
8	220-130	Inner Cast - Back
9	220-240	Cast Baffle Retention - Left
10	220-230	Cast Baffle Retention - Right
11	220-381	Left Side Cast - Charcoal Grey
	220-385	Left Side Cast - Timberline Brown
12	220-032	Brick Vermiculite - Left Side
13	936-299	Gasket Tape
14	220-029	Side Shield Door
15	220-041	Brick Vermiculite - Right Door
16	936-236	Graphite Rope
17	220-351	Right Side Cast - Charcoal Grey
	220-355	Right Side Cast - Timberline Brown
18	220-361	Right Side Door - Charcoal Grey
	220-365	Right Side Door - Timberline Brown
19	948-151	Side Door Hinge
20	220-053	Door Latch Bar - Right
21	220-047N	Side Door Latch
22	948-178	Brown Varnish Wooden Handle
	948-179	Black Varnish Wooden Handle
23	220-120	Firebox Inner Cast - Front
24	200-160	Andiron Hampton
25	220-321	Front Vents - Charcoal Grey
	220-324	Front Vents - Ivory
	220-325	Front Vents - Timberline Brown

	Part #	Description
26	220-110	Firebox Cast - Front
27	220-090	Latch Bar
28	220-331	Front Skirt - Charcoal Grey
	220-335	Front Skirt - Timberline Brown
29	220-341	Stove Base - Charcoal Grey
	220-345	Stove Base - Timberline Brown
30	220-401	Side Ashlip - Charcoal Grey
	220-405	Side Ashlip - Timberline Brown
31	220-084	Draft Control Lever
32	220-074	Cam Housing Primary
35	220-081	Primary Air - Slide Guide
36	936-238	8mm Soft Fibre Gasket - Black
37	220-085	Base Sub Cast
38	220-391	Ashlip - Charcoal Grey
	220-395	Ashlip - Timberline Brown
39	220-421	Standard Leg - Charcoal Grey
	220-425	Standard Leg - Timberline Brown
	200-931	Short Leg - Charcoal Grey
	200-935	Short Leg - Timberline Brown
40	220-078	Ash Drawer Holder
41	220-516	Ash Pan Drawer Assembly
42	220-917	Optional Blower/Fan (120V)
43	910-142	Fan Thermodisc
44	220-538	Rear Heat Shield Assembly
45	942-110	Ash Plug
46	820-249	Ash Plug Tool Handle
47	220-086	Ash Drawer Holder Cover Plate
48	948-157	Primary Air Handle



H300 DOOR ASSEMBLY

Part #	Description
70) 846-530	5/8" Door Gasket Kit
71) 220-034F	Retention Glass Top
72) 220-035F	Retention Glass
73) 936-243	7/8" Window Adhesive Tape
74) 940-333/P	Neoceram Flush Glass c/w Gasket
75) 220-441	Door & Grill - Charcoal Grey
220-445	Door & Grill - Timberline Brown
76) 948-158	Slotted Spring Tension Pin
77) 948-178	Brown Varnish Wooden Handle
948-179	Black Varnish Wooden Handle
78) 220-089N	Latch Door - Nickel Plated
79) 948-155	Hinge Pin - Bottom
80) 948-156	Hinge Pin - Top
220-546	Front Door Handle/Latch Assembly complete (not shown)
220-532	Side Door Handle/Latch Assembly complete (not shown)



H300 FIREBRICK

Part #	Description
220-960	Firebrick Set
90) 802-157	Brick Partial - 4.5" x 8.5"
91) 802-148	Brick Partial - 4.5" x 4.5"
92) 802-158	Brick Partial - 2" x 8.5"
93) 802-159	Brick Partial - 4.5" x 8.5" (cut angle)
94) 802-160	Brick Partial - 2.25" x 7"

