


MAIN ASSEMBLY

Part #	Description
1) 850-141	Small Door - Black
850-142	Small Door - Gold
850-143	Small Door - Nickel Accent
850-144	Small Door - Gold Accent
850-151	Large Door - Black
850-152	Large Door - Gold
850-153	Large Door - Nickel Accent
850-154	Large Door - Gold Accent
3) 846-302	Small Glass
4) 936-243	Glass Gasket (7/8")
5) 846-920	Glass Retainer Clips (8/set)
6) *	Screw 1/4 - 20 x 3/8"
7) 948-170/P	Small Glass Retainer
9) 846-973	Door Handle/Latch Assembly
10) 910-250	Spill Switch
12) 846-570	7/8" Gasket Repair Kit
13) 846-918	Hinge Cap - Gold (2/set)
14) *	Screw #10 - 24 x 3/4"
15) *	1/4" split lock washer
16) *	Screw #10 - 24 x 1/2"
17) 471-031	Door Retainer Clip
19) 948-101	Spring Handle - Large
490-917	Fan Assembly (120 V) Optional
20) 910-157/P	Fan motor (120 V)
22) 910-794	Power Cord
910-140	Fan HI/OFF/LOW switch




PARTS LIST

BURNER & LOGS

Part #	Description
52) 910-190	Piezo Ignitor & Nut
53) *	Control Panel
908-672	Control Panel Decal
462-560/P	Valve Assembly - S.I.T. - NG
462-561/P	Valve Assembly - S.I.T. - LP
63) 910-478	Valve S.I.T. - NG/LPG
66) 910-034	Pilot Assembly-3 flame-S.I.T. -NG
910-035	Pilot Assembly-3 flame-S.I.T. -LP
67) 904-604	Orifice #36 (NG)
904-390	Orifice #52 (LP)
68) 948-279	Burner - LP
69) 948-294	Burner - NG
70) 948-232	Air Shutter Adjusting Rod
*	Burner Tray Assy-NG
*	Burner Tray Assy-LP
72) 490-023	Deflector - Front Log
73) 460-009	Deflector - Rear Burner Front
74) 490-025	Deflector - Btm
75) 490-068	Burner/Rear Log (LP)
79) 460-011	Deflector - Rear Burner Back (NG)
80) *	Front Log
81) *	Rear Log
82) *	Top Log (each)
93) 904-537	3/8 x 12" black mall nipple.

*Not available as a replacement part.




BASE OPTIONS


Part #	Description
490-921	Complete Floor Shield
100) 948-216	Regency® Logo (Gold)
948-223	Regency® Logo (Silver)
102) 904-257	Magnetic Catch (Large)
103) *	11" Pedestal Hinge
108) 910-246	Burner ON/OFF Switch (2-way)
109) 910-272	LT. Dummy Plug
110) *	Strain Relief for power cord
121) *	Access Panel
140) 850-126	Cast Legs - Black
850-127	Cast Legs - Gold
850-128	Cast Legs - Brush Nickel

Part #	Description
490-926	Complete Pedestal
100) 948-216	Regency® Logo (Gold)
948-223	Regency® Logo (Silver)
102) 904-257	Magnetic Catch (Large)
103) *	11" Pedestal Hinge
108) 910-246	Burner ON/OFF Switch (2-way)
109) 910-272	LT. Dummy Plug
110) *	Strain Relief for power cord
123) *	Pedestal Blanking Plate
124) 820-058F	Pedestal Cover Plate
125) *	Rear Cover Plate


*Not available as a replacement part.



FLOOR SHIELD (OPTIONAL)



PEDESTAL (OPTIONAL)



LEGS (OPTIONAL)