


MAIN ASSEMBLY

Part #	Description
1. 493-005	Safety Screen
2. 494-941	Small Door - Black
494-943	Small Door - Nickel Accent
3. 490-548	Small Glass/includes Gasket
4. 846-684	1/8" x 1" Wide Window/Glass Gasket Tape (6') (936-240)
5. 494-754	Door Handle Assembly
6. 490-028	Glass Frame
7. 494-921	Door Handle
494-926	Floor heat Shield
12. 846-699	Door Gasket 3/4" Rope (5') (936-233)
14. *	Screw 10-24 x 3/4"
17. 471-031	Door Retainer Clip
19. 948-146	Wooden Handle
20. 494-917	Complete Fan Assembly (Optional)
910-157/P	Blower Motor (120V)
22. 910-813	Power Cord (120V)
25. 948-284	Flex Pipe - 3" ID
26. 904-603	Stainless Steel Hose Clamp
27. 936-197	Gasket - Flue Collar/Starter Collar
28. 936-194	Gasket - Starter Collar/Air Passage
29. 923R	Flue Starter Collar
30. W260260	Relief Frame Gasket
31. 942-117	Top Relief Plate Frame
32. W260280	Top Relief Plate Gasket
33. 290-021	Air Baffle Plate
35. *	Capscrew 1/4 x 1-3/4" NC
38. 490-081	Flue Restrictor
40. 490-520	Top Assembly
920-059	Manual

*Not available as a replacement part.



parts list


BURNER ASSEMBLY & LOG SET

Part #	Description
61.	494-774/P Valve Assembly - S.I.T. - Nat. Gas
61.	494-776/P Valve Assembly - S.I.T. - Propane
63.	911-084 SIT Valve - NG
	910-085 SIT Valve - LP
64.	911-337/P Remote Battery Box
65.	911-342 Remote Battery Box Cover
66.	911-284 Pilot Assy IPI NG 2 Flame
	911-285 Pilot Assy IPI LP 2 Flame
67.	911-010 Stepper Motor NG for 886 SIT 0.907.013
	911-011 Stepper Motor LP for 886 SIT 0.907.012
**	911-175 Remote hand held (GTMF)
**	910-036 Pilot Orifice NG
**	910-037 Pilot Orifice LP
**	911-039 Pilot Hood
**	910-432 Pilot Tube w/nuts

**	911-173 Valve/Remote Wiring Harness
	911-282 Battery Box Wiring Harness
	911-257 2 Pin Fan Wiring Harness
	911-193 Connector with Jumper Wire
	911-179 120 Volt Power Cord
	911-266/P IFC Board SIT Proflame II 7 day PV + 5 Second. FFRT w/Antenna
	911-210 External Antenna
	911-037 Flame Sensor
	911-038 Flame Electrode
	911-137 Pilot Hood Clip
	910-802 Fan Wire - Black
	910-749 Fan Wire - White
**	904-604 #36 Orifice (NG)**
	904-390 #52 Orifice (LP)**
**	936-170 Orifice Gasket
68.	936-175 Gasket - Top Plate
69.	948-280 Burner c/w Air Cap - NG/LP

71.	904-188 Clamp for Burner
72.	490-023 Front Log Deflector - NG/LP
78.	490-067 Deflector-Top Rear Log - NG
79.	490-068 Deflector-Top Rear Log - LP
81.	490-932 Complete Log Set
**	902-151 Ember
**	902-153 Rockwool
**	946-669 Platinum Embers (Bag)
**	946-708 Embaglow Embers (Bag)

** Not shown




BASE OPTIONS


Part #	Description
494-921	Complete Floor Shield
100 948-223	Regency® Logo
102. 904-257	Magnetic Catch (Large)
103. *	11" Pedestal Hinge
110 910-327	Strain Relief for Power Cord
121. 490-005	Access Panel
140. 850-126	Cast Legs - Black (4/set)
850-128	Cast Legs - Brush Nickel (4/set)

Part #	Description
494-926	Pedestal Assembly
100 948-223	Regency® Logo
102. 904-257	Magnetic Catch (Large)
103. *	11" Pedestal Hinge
110 910-327	Strain Relief for Power Cord
123. 490-070	Pedestal Blanking Plate
124. 820-058	Pedestal Cover Plate
125. 490-002	Rear Cover Plate


*Not available as a replacement part.



FLOOR SHIELD (OPTIONAL)



PEDESTAL (OPTIONAL)



LEGS (OPTIONAL)