


MAIN ASSEMBLY


Part #	Description
1) 340-038	Fan Access Plate
2) 340-103	Gasket - Fan Access Plate
3) 320-517/P	Fan Assembly 120 V
910-331/P	Fan Motor 120 V
5) 910-750	Power Cord
910-752	Wire Harness (Faceplate)
910-692	Wire Fan to Power Cord
910-737	Wire Valve to Spill Switch
7) 910-142	Fan Auto On/Off Thermodisc
8) *	Thermodisc Bracket
9) 320-070	Fan Switch Cover
13) *	Baffle Plate
17) *	Wire Holder Clip
18) *	Strain Relief
19) *	Grommet for Power Cord
340-924	Flush Louvers (Set) - Black/Gold
340-922	Flush Louvers (Set) - Black
340-926	Flush Louvers (Set) - Black/Steel
21) *	Top Flush Louver
23) *	Bottom Flush Louver
340-901	Brick Panel Set - Standard Brown
340-902	Brick Panel Set - Standard Red
33) *	Brick Panel - Right
34) *	Brick Panel - Left
35) *	Brick Panel - Back
36) *	Brick Panel - Top
37) 511-031	Brick Clips
340-094	Bottom Clips
340-043	Top Bracket
340-528	Base Brick Panel (3pc)
38) 340-043	Brick Front Trim
43) *	Stove Top
44) 340-099	Gasket Vent
918-408	Manual

* Not available as a replacement part.



FULL SCREEN FRONT INSTALLATION

Part #	Description
83)	Top Frame
84) 340-910	Full Screen Door - Black
85)	Full Screen Left Door
86)	Full Screen Right Door
87)	Bottom Frame
88)	Screw #8 x 1/2 Self Tapping
89) 910-199	Wire Clip Holder
90) 948-042	Hinge Spring



PARTS LIST

FACEPLATES, TRIMS AND HEARTHHS

Part #	Description	Part #	Description	
340-918	Faceplates and Trim (Complete) with Black Trim	172)	320-940	Hearth Trim - 1"
340-919	Oversized Faceplate	176)	320-942	Hearth Trim - 2"
74) 904-569	Fan Speed Control Knob	180)	320-944	Hearth Trim - 4"
91) *	Faceplate Side - Right	184)	320-946	Hearth Trim - 6"
92) *	Faceplate - Top	186)	904-586	Speed Control Knob c/w Spring Clip
93) *	Faceplate Side - Left Assy	190)	*	Screw #8 x 1/2" Black Self-tapping
		191)	*	Screw #8 x 1/2" Brass Plated Self-tapping
		199)	948-216	Regency Logo
340-532	Trim Set Packaged - Black	* Not available as a replacement part.		
340-533	Oversized Trim Set Packaged - Black			
340-950	Trim Set Packaged - Brass			
94) *	Trim Side - Right			
95) *	Trim - Top			
96) *	Trim Side - Left Assy			
97) 910-246	Burner ON/OFF Switch			
98) 910-330	Fan Speed Control 120 V			
99) *	Faceplate Filler			

