

MAIN ASSEMBLY

Part #	Description
1) 942-601**	Casting - Top
2) 942-621**	Casting - Side & Leg
3) 942-611**	Casting - Front
6) 770-066F	Top Relief Plate
7) W260280	Top Relief Plate Gasket
8) 770-067F	Plate Insulation Holder
9) 942-117	Top Relief Frame
10) W260260	Top Relief Frame Gasket
11) 945F	Dura-Vent Collar
12) W842051	Gasket for Flue Adaptor
13) W260108	Gasket for Inner Flue
14) *	Rear Bracket
15) 380-024	Fan Deflector - Right
16) 380-023	Fan Deflector - Left
17) 910-142	Thermodisc Switch


Part #	Description
20) 380-012	Rear Panel
25) 910-330	Fan Speed Control (120V)
26) 904-569	Knob - Fan Speed Control
28) 910-241	Burner ON/OFF Switch
29) 260-037	Rear Control Panel
35) 380-002	Firebox Bracket - Left
36) 380-003	Firebox Bracket - Right
38) 380-034	Casting Mount Bracket
45) 380-001	Door Support
46) 380-010	Baffle Plate of Firebox

Part #	Description
47) 380-011	Restrictor
50) 948-255	Latch Ojop W/J-Hook
51) 940-338/P	Replacement Glass
52) 41225	Gasket Tadpole
53) 380-008	Glass Bracket
54) 380-007	Door Frame
56) 910-157/P	Fan Motor (120 V)
57) 910-794	Power Cord (120 V)

918-516 Manual

* Not available as a replacement part.

** Last digit of part number represents colour:
3=Slate Blue, 4=Ivory, 5=Timberline Brown,
7=Seaside Sand.



BURNER & LOG ASSEMBLY

Part #	Description
380-574/P	Valve/Pilot Assembly - S.I.T. - NG
60) 910-478	Valve S.I.T. - NG/LPG
904-434	#47 Orifice - NG
63) 910-190	Piezo Ignitor & Nut
64) 908-672	Control Panel Decal
65) 490-061	Switch Plate
936-170	Orifice Gasket
66) 910-038	Pilot Assy-S.I.T. - 3 flame - NG
910-039	Pilot Assy-S.I.T. - 3 flame - LP
67) 380-013	Pilot Holder
68) W840470	Pilot Assembly Gasket
69) 380-019	Valve Shield
73) 380-032	Valve Plate
74) 380-033	Valve Door
75) 380-930	Log Set
80) 380-505	Burner Assembly - NG
88) 380-015	Burner Box Gasket
89) *	Air Shutter
90) *	Burner Box
381-969	Conversion Kit - NG to LP

