


MAIN ASSEMBLY

Part #	Description	Part #	Description	Part #	Description
1. 945F	Flue Collar/Starter Collar			382-002	Firebox Bracket Right
2. 380-007	Door frame	W801015	Touch Up Paint - Brown	15 382-105	Safety Screen Mounting Bracket (Each) *
4. 382-917	Fan Assembly (Optional)			380-024	Fan Deflector - Right
5. 383-201	Cast Front - Gray	938-337	Touch Up Paint - Cream	380-023	Fan Deflector - Left
383-205	Cast Front - Timberline Brown	9. 382-515	Rear Panel Assembly	380-001	Door Support
383-207	Cast Front - Cream	11. 382-516	Valve Cover Assembly	380-010	Baffle Plate
5a. 383-231	Cast Top Grill - Gray	12. 382-005	Safety Screen Assy	380-011	Restrictor
383-235	Cast Top Grill - Timberline Brown	13 770-066F	Top Relief Plate	20 948-255	Latch Ojop W/J-Hook
383-237	Cast Top Grill - Cream	14 W260280	Top Relief Plate Gasket	21 940-338/P	Replacement Glass
6. 383-211	Cast Top - Gray	770-067F	Plate Insulation Holder	846-687	1/4" x 5/16" Tadpole w/ Adhesive Glass Gasket (6')
383-215	Cast Top - Timberline Brown	942-117	Top Relief Frame		(41225)
383-217	Cast Top - Cream	W260260	Top Relief Frame Gasket		
7/8. 383-221	Cast Left/Right Side Comes With Legs (2 Per Side) - Gray	W842051	Gasket for Flue Adaptor		
383-225	Cast Left/Right Side Comes With Legs (2 Per Side) - Brown	W260108	Gasket for Inner Flue	919-880	Manual
383-227	Cast Left/Right Side Comes With Legs (2 Per Side) - Cream	350-022	Cast Mount Bracket (Each)		
		382-001	Firebox Bracket Left		* Not available as a replacement part.



parts list

BURNER & LOG ASSEMBLY

Part #	Description
16. 911-084	Valve - NG 885 SIT IPI
16. 911-085	Valve - LP 885 SIT IPI
17. 911-010	Stepper Motor - NG
17. 911-011	Stepper Motor - LP
18. 911-276	Pilot assembly IPI NG 2 Flame
911-277	Pilot assembly IPI LP 2 flame
910-036	Novasit Pilot Orifice - NG
910-037	Novasit Pilot Orifice - LP
18a. 911-039	Novasit Pilot Hood 2 Way
911-137	Pilot Hood Clip
18b. 911-037	Flame Sensor
18c. 911-038	Flame Electrode
19. 904-434	Burner Orifice #47 - NG
19. 904-575	Burner Orifice #55 - LP
904-529	5/32" Allen Key - Pilot Orifice
936-170	Burner Orifice Gasket
W840470	Pilot Assembly Gasket (Each)
20. 382-574/P	Valve Assembly - NG
382-776/P	Valve Assembly - LP
21. 380-015	Valve Assembly Gasket
904-658	1/2" X 18" Flex Line - Gas Inlet
22. 911-266/P	IFC Board SIT Profilm II 7day PV+5 Sec.FFRT 0.584.625
911-175	Hand Held Remote Control GTMFL 0.584.042
911-179	ASM 120 Volt Power Cord Assembly
911-173	Valve/Remote Wiring Harness 584.924
911-177	4 Position Wire Harness Fan & Light Proflame 11
911-178	2 Position Wire Harness On/Off Switch
910-998	Halogen Light Socket Assembly
910-997	Halogen Light Bulb 120 Volt/20 Watt/JCD Bi-Pin/ GY6.35
910-157/P	Replacement Blower Motor Only With Squirrel Cage
948-131	Blower Screens (Each)
911-093	10 Foot Extension Cord
911-027	Battery Holder W/9V Snap in 4-AA Batteries
W842051	Starter Collar Gasket - Outer
W260108	Starter Collar Gasket - Inner
23. 380-930	Log Set
39. 382-016	Valve Cover Plate Left
42. 382-012	Valve Cover Plate Right
41. 382-015	Valve Access Door
40. 382-018	Valve Cover Plate Front
43. 910-246	On/Off Switch
44. 382-017	Valve Cover
45. 911-242	Reset Switch
46. 910-432	Pilot Tubing with Nuts

350-530 Burner Assembly - Natural Gas/Propane

*Note: Not available as a replacement part.

