


Main Assembly

Part #	Description	Part #	Description
1) 730-550	Burner Tube Assembly NG/LP	16) 743-221	Cast Right Charcoal Grey
2) 770-066F	Firebox Assembly	743-224	Cast Right Cream
3) 770-066F	Pressure Relief Frame	743-225	Cast Right Timberline Brown
3a) W260280	Pressure Relief Frame Gasket	743-227	Cast Right Seaside Sand
4) 740-542	Transition Box Assembly	17) 770-066F	Top Pressure Relief Plate
6) 740-542	Front Door Assembly	17A) W260280	Top Pressure Relief Plate Gasket
7) 743-160	Front Brick Inlay	18) 904-012	Top Pressure Relief Bolt (Each)
8) 740-548	Rear Relief Door Assembly	19) 743-231	Cast Front Charcoal Grey
8) 740-059	Rear Relief Door Assembly Gasket	743-234	Cast Front Cream
9) 743-513	Rear Panel Assembly	743-235	Cast Front Timberline Brown
10) 945F	Starter Collar	743-237	Cast Front Seaside Sand
10A) W842051	Starter Collar Gasket Outer	20) 743-271	Top Cast Grill Charcoal Brown
10A) W842051	Starter Collar Gasket Inner	743-274	Top Cast Grill Cream
743-917	Fan Kit Complete (Optional)	743-275	Top Cast Grill Timberline Brown
12) 560-517/P	Fan Assembly	743-277	Top Cast Grill Seaside Sand
910-331/P	Fan Motor	21) 743-100	Safety Screen
13) N/A	Lower Air Passage Assembly	23) 743-241	Cast Leg Charcoal Grey (each)
14) 743-201	Cast Top Charcoal Grey	743-244	Cast Leg Cream (each)
742-204	Cast Top Cream	743-245	Cast Leg Timberline Brown (each)
743-205	Cast Top Timberline Brown	743-247	Cast Leg Seaside Sand (each)
743-207	Cast Top Seaside Sand	24) 846-687	1/4" x 5/16" Tadpole w/ Adhesive Glass Gasket (6') (41225)
15) 743-211	Cast Left Charcoal Grey	26) 948-219	Hampton Logo Plate
743-214	Cast Left Cream	27) 743-160	Inner Brick Inlay
743-215	Cast Left Timberline Brown	28) 743-006	Plate Switch Cover
743-217	Cast Left Seaside Sand		






Burner & Log Assembly

84

83

BRICK PANEL SET

83



56 | Hampton® H35E-11 Direct Vent Freestanding Gas Stove