




PROFLAME REMOTE SYSTEM GTMF WITH OPTIONAL FAN




CAUTION: Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.

Caution: Ensure that the wires do not touch any hot surfaces and are away from sharp edges.


OPTIONAL FAN WIRING DIAGRAM WITHOUT PROFLAME GTMF SYSTEM



**Electrical Connection Alternative Scheme "A",
Power at Stove**



**Electrical Connection Alternative Scheme "B",
Power at Switch**



Note: If optional DC adapter is used—be sure fan is in ON position.

Caution: Ensure that the wires do not touch any hot surfaces and are away from sharp edges.

CAUTION: Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.