


MAIN ASSEMBLY

Part #			Description			Part #			Description		
1	770-523	Thermodisc Cage Assy	10	432-917	Fan Assembly						
2	904-434	Orifice #47 NG	11	437-018	Access panel						
	904-241	Orifice #56 LP	12	437-024	Screen Frame						
3	911-004	886 Proflame Valve	13	433-538	Door Assembly						
4	437-578	Valve Assembly	14	437-023	**Clean Front Face						
5	437-012	Bracket	15	433-511	**Firebox Assembly						
6	437-525	Burner Assembly		**	Not a replacement part						
7	437-015	Burner Filler Tray Assy		911-006	Pilot Assembly - NG						
8	437-004	Pilot Cover		911-007	Pilot Assembly - LP						
				919-120	Manual						



ACCESSORIES

	Part #	Description
1	434-044	Enamel Panel Top
2	434-042	Enamel Panel Left
3	434-041	Enamel Panel Right
4	434-043	Enamel Panel Back

