


MAIN ASSEMBLY

Part #	Description		
1) 946-705	Power Vent Kit	904-658	Inlet Gas Flex Line SS
3) 586-070	Bottom Cover NG / LP	430-011	Flue Collar Gasket
4) 586-525	Burner Assembly -NG	586-047F	Relief plate door
586-530	Burner Assembly-LP	586-048	Plate Relief Gasket
6) 586-574E/P	Valve Assembly -NG	586-039	Valve Tray Gasket
586-576E/P	Valve Assembly-LP	430-011	Inner Flue Collar Gasket
7) 911-006	Pilot Assy - 886 - S.I.T. - NG	586-017F	Flue Restrictor Plate
911-007	Pilot Assy - 886 - S.I.T. - LP	586-016F	Gas line cover
8) 904-593	Orifice # 40 (NG)	586-068	Top nailing strip
904-345	Orifice # 53 (LP)	596-045F	Side nailing strip
9) 948-484	Slide Hinge	596 072F	Bottom nailing strip
911-012	Ignition Board (DBC)	940-361/P	Flush Glass
		586-029	Flush Glass Frame (shown on next page)
		918-949	Manual



ACCESSORIES

Part #	Description
10) 586-907	Reflective Stainless Steel Inner Panels
586-908	Black Enamel Inner Panels
11) 586-914	Faceplate Black
586-916	Faceplate Sunset Bronze
586-917	Faceplate Brushed Stainless
946-671	Cobalt Blue Glass Crystals
946-672	Natural River Pebbles
946-673	White River Pebbles
946-674	Ceramic Spa Stones
946-706	BX Cable- 20ft
946-707	BX Cable- 60ft
946-700	GT Proflame Remote Control
946-701	GTM Proflame Remote Control
946-702	GTMF Proflame Remote Control

