


MAIN ASSEMBLY

Part # Description			Part # Description		
1	397-929	Screen assembly	12	416-018	Fan bracket
2	396-035	Door Frame	13	396-043	FB Liner Retainers
3	936-159	Door Gasket	14	396-901	Brick Panels - Brown
4	940-371/P	Door Glass		396-902	Brick Panels - Red
5	398-525/P	Glass Burner (not shown)	15	396-908	Enamel Panels
5a	398-530	Log burner		396-525	Glass Burner Assembly
6	910-038	Pilot Assembly NG		Various	Glass Crystals
	910-039	Pilot Assembly LP	16	296-145	Pilot Shield
7	910-036	Pilot orifice NG	17	396-042/f	Door Tool
	910-037	Pilot orifice LP	19	416-535	Flue adaptor assembly
8a	416-019	Filler section- right	20	398-018	Flue Connector Gasket
8b	396-114	Filler section- left		919-275	Manual
9	910-073	DC sparker	*	Not Shown	
	910-074	DC sparker wire	*	911-149	Fan Thermodisc
10	910-568	Sit valve 820	*	904-790	Magnets (ea)
11/12	416-517/P	Fan assembly	*	820-389	Thermodisc bracket
11	911-071/P	Fan Motor only		398-003	Log Stand
				398-930	Log Set
				396-112	Glass Gasket Retainer
				904-691	Glass clip (ea)
				910-372	Valve extension knob Hi/Lo
				910-373	Valve extension knob pilot/ON/OFF
				904-946	NG burner orifice #37
				904-947	LP burner orifice #53
			21	910-033	Pilot Assembly NG
				910-039	Pilot Assembly LP
			22	910-341	Thermopile
			23	910-356	Thermocouple
			*	910-096	3 way pilot hood
			*	910-030	Spark electrode
			*	910-432	Pilot Tube

PARTS LIST



LOW PROFILE FACEPLATE

	Part #	Description
41	416-922	3 sided low profile faceplate - Sunset bronze
	416-924	3 sided low profile faceplate - Metallic black
	416-925	3 sided low profile faceplate - Iron grey

