










MAIN ASSEMBLY

Part #	Description	Part #	Description
1) 521-527	Flue Collar Inner Assembly	16) 526-027	Gasket
2) 502-008	Flue Collar Outer	17) 526-005F	Top Relief Plate
		18) 904-841	Capscrew
5) 904-751	Capscrew 1/4 x 4-1/2		
6) W260280	Gasket Top Relief Plate	946-671	Colbalt Glass
7) 770-066F	Top Relief Plate	946-674	Ceramic Spa Stones
8) 942-117	Top Relief Frame	946-680	GTM Remote Control
9) W260260	Top Relief Frame Gasket	910-576	Cover Wall Mount
12) 526-005F	Door Frame Assembly, no Glass	910-572	Receiver GTM SIT w/Batt & Cover
351/P Glass			
13) 526-006	Faceplate	946-556	Heat Wave Kit
		946-570	Heat Release Kit
14) 526-907	Inner Reflective Panel Stainless Steel	522-969	LP Converison Kit
526-908	Inner Reflective Panel Enamel Black		
526-909	Inner Panel Metallic Black	918-758	Manual
*	Left Side Panel		
*	Back Panel		
*	Right Side Panel		
15) 526-911	Faceplate and Door Frame - Platinum		
526-913	Faceplate and Door Frame - Blue		
526-914	Faceplate and Door Frame - Black		
526-915	Faceplate and Door Frame - Red		

* Not available as a replacement part.

PARTS LIST

MAIN ASSEMBLY



BURNER ASSEMBLY

Part #	Description
20) 526-002	Pilot Assembly Shield
21) 526-000	Firebox Base
22) 526-525	Burner Assembly NG/LP
23) 502-061	Shield Pilot
24) 910-586	Pilot Assembly
25) 904-240	NG Orifice #37
904-345	LP Orifice # 53
26) 910-568	Valve NG/LP 820 SIT

