


MAIN ASSEMBLY

Part #	Description	Part #	Description
1	Burner Assembly	904-568	Orifice # 44 NG
2	770-523 Thermodisc cage	904-575	Orifice # 55 LP
3	437-515 Valve Assembly	911-004	886 Proflame Valve
4	432-917 Fan Assembly	919-125	Manual
5	437-024 Screen glass guard		
6	433-538 Glass Door Assembly		
7	** Clean Front Assembly		
8	** Firebox Assembly		
	** Not a replacement part		



BURNER & LOG ASSEMBLY

Part Description

53) 430-055	Gasket - Valve Access Plate - NG/LP
54) 910-421	Pilot ON/OFF Extension Knob
55) 910-422	Flame HI/LOW Extension Knob
435-574E/P	Valve Assy - Natural Gas
435-576E/P	Valve Assy - Propane
57) 911-004	Valve SIT - NG
911-005	Valve SIT - LP
58) *	Valve Bracket
59) *	Firebox Base
60) *	Valve Tray
66) 911-006	Pilot Assy - 886 - S.I.T. - NG
911-007	Pilot Assy - 886 - S.I.T. - LP
904-568	Orifice #44 - Natural Gas
904-575	Orifice #55 - Propane
936-170	Orifice Gasket
67) *	Pilot Holder
68) W840470	Pilot Assembly Gasket
79) 433-525	Burner Assy - NG/LP
82) 433-024	Burner Grate Assembly - NG/LP
83) *	Rear Log Support Bracket - NG/LP
85) 431-930	Log Set
86) 430-097	Air Deflector-Left
87) 433-018	Air Deflector-Right

*Not available as a replacement part.

