

PARTS LIST

MAIN ASSEMBLY

Part # Description

434-907 Reflective Panel Stainless Steel (Optional)
434-908 Reflective Panel Black Enamel (Optional)

- 1) * Panel Rear P33S (SS / Black Enamel)
- 2) * Panel Top P33S (SS / Black Enamel)
- 3) * Panel Side Left P33S (SS / Black Enamel)
- 4) * Panel Side Right P33S (SS / Black Enamel)

- 8) 434-913 Faceplate Assembly Complete Painted Blue
- 434-914 Faceplate Assembly Complete Black
- 434-915 Faceplate Assembly Complete Painted Red
- 434-916 Faceplate Assembly Complete Sunset Bronze
- 434-917 Faceplate Assembly Complete Stainless Steel

- 10) 434-023 Mounting Plate

- 13) 434-514 Faceplate Support Bracket Assembly - Set
- 909-924 Bumper Rubber W/Machine Screw 8-32 x 3/8"
- 904-925 Cap Assy Brushed Stainless 3/4" diameter.

- 14) 434-033 Control Mounting Plate
- 15) 434-574/P Valve Assembly P33S-NG4 SIT Packaged
- 434-576/P Valve Assembly P33S-LP4 SIT Packaged

- 16) 341-525 Burner Assembly NG/LP c/w Cap

- 17) * Outerbox Assembly
- 18) * Firebox Assembly

- 19) 433-538 Flush Door Assembly Complete
- 940-088/P Glass (Flush)
- 904-691 U-Clip
- 936-155 Glass Gasket

Part # Description

- 20) 434-011 Fire box base
- 21) 434-032 Control Shield
- 22) 948-247 Door Handle
- 23) 434-018F Heat Deflector
- 24) 432-917 Fan Assembly
- 25) 910-331/P Fan Motor (120 Volts)
- 432-966 Fan Switch Assy (120 Volts)
- 27) 910-813 Power Cord (120 Volts)
- 28) 910-330 Fan Speed Control
- 29) 904-586 Knob - Speed Control
- 30) 910-142 Thermodisc - Fan Auto ON/OFF

- 31) 918-757 Manual

* Not available as a replacement part.

